

TP9600 P25 Portable Radio

User Manual

MPG-00002 - Issue 03 - September 2025

Contents

Contents	2
Contact Information	10
Preface	11
Scope of Manual	11
Alerts	11
Associated Documentation	11
Acronyms	12
Publication Record	12
1 For Your Safety	13
1.1 Intrinsically Safe and Non-Incendive Portable Radios and Accessories	13
1.2 Radio Frequency Exposure Information	14
1.2.1 Using this radio	14
1.2.2 Controlling exposure to RF energy	14
1.2.3 Compliance with RF energy exposure standards	15
1.2.4 Conformité aux normes d'exposition à l'énergie RF	15
1.3 Radio Frequency Emissions Limits in the USA	15
1.3.1 CFR Title 47 Part 15.19 (a) (1) - Receivers	15
1.3.2 CFR Title 47 Part 15.19 (a) (3) - All other devices	15
1.4 Radio Frequency Emissions Limits in Canada	16
1.5 USA Public Safety Bands (764–776MHz and 794–806MHz)	16
1.5.1 Low-power channels	16
1.5.2 Use of encryption	16
1.6 EMC Regulatory Compliance in Australia	16
1.7 Frequency Band Reserved for Distress Beacons	16
1.8 Health, Safety and Electromagnetic Compatibility in Europe	17
1.8.1 Intended purpose of product	17
1.8.2 Restrictions	17
1.8.3 Declaration of conformity	17
1.9 Interference with Electronic Devices	17

1.10 Potentially Explosive Atmospheres and Blasting Areas	18
1.11 Radio Installation and Operation in Vehicles	18
1.12 Vehicle Charger Installation and Operation	19
1.13 Multicharger Safety Information	19
1.14 Electromagnetic Compatibility in European Vehicles	19
1.15 Unapproved Modifications or Changes to Radio	19
1.15.1 Attaching of labels	19
1.15.2 Use of lithium-ion batteries	20
1.15.3 Short-circuiting battery contacts	20
2 Before Using the Radio	21
2.1 Battery Warning	21
2.2 Attaching Labels to the Radio or Battery	21
2.3 Attaching a Label to the Front Panel	23
2.4 Charging the Battery before First Use	24
2.4.1 Lithium-ion batteries	24
2.5 Attaching the Battery	24
2.6 Removing the Battery	25
2.7 Attaching the Antenna	25
2.8 Removing the Antenna	25
2.9 Attaching a Belt Clip	26
2.10 Removing a Belt Clip	26
2.11 Installing an Audio Accessory	26
2.11.1 Removing the accessory cover	27
2.11.2 Installing an accessory connector	27
3 Getting Started	28
3.1 Setting and Viewing the Radio's Time and Date	28
3.1.1 Setting the time, date, and time format	28
3.1.2 Viewing the time and date	28
3.2 About the Radio	28
3.2.1 P25 programming modes	28
3.2.2 Lack of static noise	29
3.2.3 Active noise cancellation	29

3.2.4 Coverage	29
3.2.5 What is audible on an analog channel	29
3.3 About the Radio Controls	30
3.4 Understanding the Radio Display	33
3.4.1 Radio display icons	33
3.5 Understanding the Radio Indicators	34
3.5.1 Status indicators	35
3.5.2 Audible tones	36
3.5.3 Voice annunciation	36
3.6 Using Function Keys to Access Frequently Used Features	37
3.6.1 Viewing the function key settings	37
3.7 Navigating the Radio's Menus	38
3.7.1 Using the main menu	38
3.8 Using the Alphanumeric Keys to Search a List	39
3.9 Accessing Frequently Used Menus	39
3.9.1 Using the scroll key quick access menu	39
3.9.2 Using the left selection key quick access menu	39
4 Basic Operation	40
4.1 Turning the Radio On and Off	40
4.1.1 Security lock on power-up feature	40
4.2 Adjusting the Speaker Volume	40
4.3 Securing the Keypad	41
4.3.1 Locking or unlocking the keypad	41
4.4 Holding the Radio	41
4.5 Speaking into the Radio	41
4.6 Using a Bluetooth Audio Device	42
4.6.1 Bluetooth audio compatibility with Tait radios	42
4.6.2 Wearing the Bluetooth audio device	42
4.6.3 Pairing and disconnecting a Bluetooth audio device with the radio	42
4.6.4 Pairing a Bluetooth audio device with the radio for the first time	43
4.6.5 Managing your Bluetooth audio devices	43
4.6.6 Disconnecting the Bluetooth audio device	43
4.6.7 Reconnecting the Bluetooth audio device	44

4.6.8 Changing the way the Bluetooth audio device reconnects	44
4.6.9 Getting the best performance from the Bluetooth audio device	44
4.7 Turning On Active Noise Cancellation	45
4.7.1 Turning active noise cancellation on or off	45
4.8 Changing the Radio's Operating Mode	46
4.9 Limiting Call Time	46
4.10 Checking Recent Calls	46
5 Operating on Conventional Channels	47
5.1 Analog Channel Operation Only	47
5.1.1 Setting your status	47
5.1.2 Resending calls automatically	47
5.1.3 Bypassing the repeater and communicating directly with other radios	48
5.2 P25 Channel Operations	49
5.2.1 Selecting a zone	49
5.2.2 Selecting a channel	50
5.2.3 Understanding talkgroups	52
5.2.4 Making a call	52
5.2.5 Making a phone call or DTMF patch call	55
5.2.6 Call alert	56
5.2.7 Bypassing the repeater	56
5.2.8 Sending and receiving a status message	56
5.2.9 Radio inhibit and uninhibit	57
5.2.10 Radio monitor	58
5.2.11 Transmitting at low power	58
5.3 Using the Radio in Different Repeater Areas	59
5.3.1 Selecting a voting group	59
5.3.2 Suspending a channel from a voting group	60
6 Operating on P25 Trunking Networks	61
6.1 About P25 Trunking	61
6.2 Checking that the System is Available	61
6.2.1 Registration is unsuccessful	61
6.2.2 Service is lost	61

6.2.3 Site trunking operation	62
6.2.4 P25 phase 2 fallback mode	62
6.2.5 Failsoft operation	62
6.3 Making a Talkgroup Call	62
6.3.1 To make a talkgroup call on a trunking system	62
6.4 Utilizing Active Noise Cancellation when Calling a Talkgroup	63
6.5 Receiving a Talkgroup Call	64
6.6 Making an Individual Call	64
6.6.1 To make a call to one radio on a trunking system	64
6.7 Utilizing Active Noise Cancellation when Making an Individual Call	64
6.8 Receiving an Individual Call	64
6.9 Emergency Calls	65
6.9.1 Making an emergency call	65
6.9.2 Receiving an emergency call	65
6.10 Making a Phone Call	65
6.10.1 To make a phone call on a trunking system	65
6.11 Dynamic Regrouping	66
6.11.1 To send a dynamic regrouping request	66
7 P25 Services	67
7.1 P25 Emergency Operations	67
7.1.1 About emergency calls	67
7.1.2 Making a priority call	68
7.1.3 Standard emergency mode	68
7.1.4 About manual emergency operation	69
7.1.5 Accessing emergency location information	70
7.2 Call Alert	71
7.2.1 Sending a call alert page	71
7.2.2 Answering a call alert page	71
7.3 Messages	71
7.3.1 Sending a message	71
7.4 Radio Check	72
7.5 Radio Unit Monitor	73
7.5.1 Sending a radio unit monitor request	73

7.6 Status Request	73
7.6.1 Sending a status request	73
7.7 Status Update	74
7.7.1 Sending a status update	74
8 Scanning	75
8.1 About Scanning	75
8.2 Activating Standard Scanning	76
8.2.1 Selecting a standard scanning group	76
8.3 Activating Background Scanning	76
8.3.1 Turning a background scanning on:	76
8.3.2 Changing the background scanning group assigned to the function key	76
8.4 Activating In-Zone Scanning	77
8.4.1 Turning in-zone scanning on	77
8.5 Activating Talkgroup Scanning	77
8.5.1 Turning talkgroup scanning on	77
8.6 Making a Call While Scanning	78
8.7 Suspending a Channel from a Scanning Group	78
8.7.1 Temporarily removing a captured group member from the scanning group	78
8.8 Editing a Scanning Group	78
8.8.1 Selecting a group to edit	78
8.8.2 Icons and meanings	79
8.8.3 Viewing group membership	79
8.8.4 Adding a channel to a group	79
8.8.5 Deleting a channel from a group	80
8.8.6 Changing a group's transmit channel	80
8.8.7 Changing a group's first or second priority channel	80
9 Location Services	81
9.1 About Location Information	81
9.2 About Location Statuses	81
9.3 Viewing Location Information	82
10 Loneworker Monitoring	83
10.1 Activating Loneworker Monitoring	83

10.2 Responding to a Loneworker Alarm	84
11 Encryption	85
11.1 About Encryption	85
11.1.1 About the proper key detect feature	85
11.2 Encrypting Calls	85
11.2.1 Turning encryption on or off	86
11.3 Making an Encrypted Call	86
11.4 Receiving an Encrypted Call	86
11.5 Changing the Radio's Encryption Key	87
11.5.1 Changing the transmit encryption key	87
11.5.2 Changing the transmit encryption key back to the default setting	87
11.5.3 Changing the encryption keyset	87
11.6 Removing Encryption Keys from the Radio	87
11.6.1 Deleting an encryption key	87
11.6.2 Deleting all encryption keys	88
11.7 Updating Encryption Keys Over-The-Air	88
12 Customizing Radio Settings	89
12.1 Extending Battery Life on Shift	89
12.1.1 Turning low power transmit on or off	89
12.2 Changing the Color Mode	90
12.2.1 Changing the color mode:	90
12.3 Changing the Volume of all Audible Indicators	90
12.3.1 Changing the volume of the radio's audible tones	90
12.4 Changing the Volume of Keypress Tones	91
12.4.1 Changing the volume of the radio's keypress tones	91
12.5 Changing to Quiet Operation	91
12.5.1 Turning quiet operation on or off	91
12.6 Changing to Silent Operation	92
12.6.1 Turning silent operation on or off	92
12.7 Turning on Backlighting	93
12.7.1 Turning backlighting on or off	93
12.7.2 Turning backlighting on momentarily	93

12.8 Adjusting the Display Orientation	94
12.8.1 Rotating the display	94
13 Failsoft Mode Operation	95
13.1 Radio-based Failsoft	95
13.2 Infrastructure Failsoft	95
14 Troubleshooting	96
14.1 Unconnected Calls	96
14.2 The Radio won't Turn On	97
14.3 Identifying the Radio's Audible Tones	97
14.4 Viewing Radio Information	98
14.4.1 Checking the version of the radio using the PTT button	98
14.5 General Care	98
14.5.1 Cleaning the radio	98
14.5.2 Cleaning the contacts of the battery	99
14.6 Running Diagnostic Tests	99
15 Simplified Declaration of Conformity	101

Contact Information

Tait Communications Corporate Head Office

Tait International Limited
P.O. Box 1645
Christchurch
New Zealand

Imported into the EU by:
Tait Communications
GmbH
Strozzigasse 10/14
Vienna 1080
Austria

Imported into the UK by:
Tait Europe Limited
Unit A, Buckingham Business
Park
Anderson Road
Swavesey
Cambridge, CB24 4UQ
United Kingdom

For the address and telephone number of regional offices,
refer to our website: www.taitcommunications.com

Copyright and Trademarks

All information contained in this document is the property
of Tait International Limited. All rights reserved.
This document may not, in whole or in part, be copied,
photocopied, reproduced, translated, stored, or reduced to
any electronic medium or machine-readable form, without
prior written permission from Tait International Limited.

The word TAIT, TAITNET and the TAIT logo are
trademarks of Tait International Limited.

All trade names referenced are the service mark,
trademark or registered trademark of the respective
manufacturers.

By using a Tait product you are agreeing to be bound by
the terms of the Tait Software Licence Agreement. Please
read the Tait Software Licence Agreement carefully before
using this Tait product. If you do not agree to the terms of
the Tait Software Licence Agreement, do not use the Tait
Product. The full agreement is available at
www.taitcommunications.com/our-resources/legal#Tait_Software_Licence_Agreement

Disclaimer

There are no warranties extended or granted by this
document. Tait International Limited accepts no
responsibility for damage arising from use of the
information contained in the document or of the
equipment and software it describes. It is the responsibility
of the user to ensure that use of such information,
equipment and software complies with the laws, rules and
regulations of the applicable jurisdictions.

Enquiries and Comments

If you have any enquiries regarding this document, or any
comments, suggestions and notifications of errors, please
contact your regional Tait office.

Updates of Manual and Equipment

In the interests of improving the performance, reliability or
servicing of the equipment, Tait International Limited
reserves the right to update the equipment or this
document or both without prior notice.

Intellectual Property Rights

This product may be protected by one or more patents or
designs of Tait International Limited together with their
international equivalents, pending patent or design
applications, and registered trade marks, for a complete list
please check www.taitcommunications.com/our-resources/legal#Intellectual_Property

The AMBE+2™ voice coding Technology embodied in this
product is protected by intellectual property rights
including patent rights, copyrights and trade secrets of
Digital Voice Systems, Inc. This voice coding Technology is
licensed solely for use within this Communications
Equipment. The user of this Technology is explicitly
prohibited from attempting to decompile, reverse engineer,
or disassemble the Object Code, or in any other way
convert the Object Code into a human-readable form.

Environmental Responsibilities



Tait International Limited is an environmentally
responsible company which supports waste
minimization, material recovery and restrictions
in the use of hazardous materials. The European
Union's Waste Electrical and Electronic
Equipment (WEEE) Directive and UK WEEE Regulation
2013 requires that this product be disposed of separately
from the general waste stream when its service life is
over. For more information about how to dispose of your
unwanted Tait product, visit the Tait WEEE website at
www.taitcommunications.com/our-resources/compliance#WEEE. Please be environmentally
responsible and dispose through the original supplier, or
contact Tait International Limited.

Tait will comply with environmental requirements in
other markets as they are introduced.

Preface

Scope of Manual

This manual provides information about all TP9600 P25 Portable Radios.

To check the radio's firmware version, see [Viewing Radio Information on page 98](#). If the radio does not operate as expected, please contact the radio provider for assistance.

Alerts

Please follow exactly any instruction that appears in the text as an 'alert'. An alert provides necessary safety information as well as instructions about the proper use of the product. This manual uses the following types of alert:



Warning This alert is used when there is a hazardous situation which, if not avoided, could result in death or serious injury.



Caution This alert is used when there is a hazardous situation which, if not avoided, could result in minor or moderate injury.



This alert is used to highlight significant information that may be required to ensure that you perform procedures correctly, or to draw your attention to ways of doing things that can improve your efficiency or effectiveness.

Associated Documentation

The following associated documentation for this product is available on the [Tait Partner Portal](#).

- MPD-00002-xx TP8000/TP9000 Battery Charging Guide
- MPD-00031-xx TP9000 Quick Start Guide
- MPG-00004-xx TP9600 Specifications Manual
- MPG-00006-xx Safety and Compliance Information for Intrinsically Safe Portable Radios with Division 1 and Non-Incendive Certification
- MPG-00007-xx TP9500/TP9600 Div 1 Quick Start Guide
- MTA-00011-xx Portable and Mobile Radio Safety and Compliance Information

The characters **xx** represent the issue number of the documentation.

Technical notes are published from time to time to describe applications for Tait products, to provide technical details not included in manuals, and to offer solutions to any problems that arise. Look for new or updated technical notes on the [Tait Partner Portal](#).

Acronyms

Acronym	Definition
RF	Radio Frequency
Li-ion	Lithium-ion
RSM	Remote Speaker Microphone
SFE	Software Feature License
PTT	Push-To-Talk
HSP	Headset Profile
HFP	Handsfree Profile
PABX	Private Automatic Branch Exchange
PSTN	Public Switched Telephone Network

Publication Record

Issue	Publication Date	Description
03	September 2025	Added Remote Speaker Microphone function on Active Noise Cancellation Added analog mode operations Added TP9600 Div 1 content
02	July 2021	Updated scanning icon Added information around colored radios
01	December 2019	First release

1 For Your Safety

Before using the radio, please read the following important safety and compliance information.

1.1 Intrinsically Safe and Non-Incendive Portable Radios and Accessories

Intrinsically Safe (IS) and Non-Incendive (NI) products are certified by a third party to be in compliance with the published and relevant standards for equipment meant for use in particular hazardous locations, or in potentially explosive atmospheres.



Warning Explosion Hazard! IS/NI certification applies only while the product is used in accordance with these instructions.



Warning Explosion hazard! Ensure that the ratings printed on a label on the equipment will permit your IS/NI radio and accessories to be used in your hazardous location. See MPG-00006-xx Safety and Compliance Information for Intrinsically Safe Portable Radios with Division 1 and Non-Incendive Certification for more information.



Warning Explosion hazard! Use only a Tait-supplied, IS/NI-approved battery, charger, antenna, or audio accessory with an IS/NI radio. Fitting a battery or accessory that is not IS/NI-approved, or using a charger that is not IS/NI-approved creates a risk of explosion which could cause serious injury or death. For an up-to-date list of approved accessories, contact your regional Tait office.



Warning Explosion hazard! Do not charge the battery, change the antenna, battery or audio accessory, or allow any other antenna port connection in a hazardous location. An explosion could cause serious injury or death.



Warning Substitution of components may impair intrinsic safety.

For Intrinsically Safe and Non-Incendive Portable Radios and Accessories, please refer to MPG-00006-xx Safety and Compliance Information for Intrinsically Safe Portable Radios with Division 1 and Non-Incendive Certification, supplied with the radio and available on the Tait Partner Portal, <https://partnerinfo.taitradio.com/>.

1.2 Radio Frequency Exposure Information



For individual safety and to ensure compliance with the radio frequency (RF) exposure guidelines of the United States Federal Communication Commission's (FCC), Industry Canada, and those from other administrations, please read the following information before using this radio.

1.2.1 Using this radio

This radio should only be used for work-related purposes (it is not authorized for any other use) and when the user is fully aware of, and can exercise control over, exposure to RF energy. To prevent exceeding FCC RF exposure limits, the user must control the amount and duration of RF that they and other people are exposed to.

It is also important that you:

- do not remove the RF Exposure label from the radio
- ensure this RF exposure information accompanies the radio when it is transferred to other users
- do not use the radio if you do not adhere to the guidelines on controlling your exposure to RF.

1.2.2 Controlling exposure to RF energy

This radio emits radio frequency (RF) energy or radio waves primarily when calls are made. RF is a form of electromagnetic energy (as is sunlight), and there are recommended levels of maximum RF exposure.

To control your exposure to RF and comply with the maximum exposure limits for occupational/controlled environments, follow these guidelines:

- Do not talk (transmit) on the radio more than the rated transmit duty cycle. This is important because the radio radiates more energy when it is transmitting than when it is receiving.
- When listening and talking on the radio, hold it upright in front of your face so that it is at least one inch (2.5cm) away from any part of your face. Keeping the radio at the recommended distance is important because exposure to RF decreases rapidly the further away the antenna is from your body.
- Keep the antenna at least one inch (2.5cm) from your face at all times.
- If you wear the radio, you must always put it in a carrying accessory that has been specifically approved by Tait for this radio. Using non-approved body-worn accessories may mean you expose yourself to higher levels of RF than recommended by the FCC's occupational/controlled environment RF exposure limits.
- Ensure you only use Tait-approved antennas, batteries, and accessories.

For more information on what RF energy is and how to control your exposure to it, visit the FCC website at www.fcc.gov/oet/rfsafety/rf-faqs.html.

1.2.3 Compliance with RF energy exposure standards

This two-way radio complies with these RF energy exposure standards and guidelines:

- United States Federal Communications Commission, Code of Federal Regulations; 47 CFR §§ 1.1307, 1.1310, and 2.1093.
- American National Standards Institute (ANSI) / Institute of Electrical and Electronic Engineers (IEEE) C95.1-1992.
- Institute of Electrical and Electronic Engineers (IEEE) C95.1-1999 Edition.
- European Directive 2004/40/EC on minimum health and safety requirements regarding the exposure of workers to the risks arising from physical agents (electromagnetic fields).

This radio complies with the IEEE and ICNIRP exposure limits for occupational/controlled RF exposure environments at operating duty factors of up to 50% talk to 50% listen.

1.2.4 Conformité aux normes d'exposition à l'énergie RF

Cette radio émetteur-récepteur se conforme aux normes et aux règlements d'exposition à l'énergie RF:

- La Commission fédérale de la communication des Etats-Unis, Code de règlements fédéraux (CFR) Titre 47 Sections 1.1307, 1.1310, et 2.1091 (radios mobiles) ou et 2.1093 (radios portatives).
- American National Standards Institute (ANSI) / Institute of Electrical and Electronic Engineers (IEEE) C95. 1-1992.
- Institute of Electrical and Electronic Engineers (IEEE) C95.1-1999 Edition.
- La directive européenne 2004/40/EC concernant les prescriptions minimales de sécurité et de santé relatives à l'exposition des travailleurs aux risques dus aux agents physiques (champs électromagnétiques).

Cette radio se conforme aux limites d'exposition de l'IEEE (FCC) et ICNIRP pour les environnements d'exposition au rayonnement RF professionnel et contrôlé aux cycles de marche de 50% en mode transmission et 50% en mode réception.

1.3 Radio Frequency Emissions Limits in the USA

1.3.1 CFR Title 47 Part 15.19 (a) (1) - Receivers

Part 15 of the FCC Rules imposes RF emission limits on receivers. This radio complies with Part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

1.3.2 CFR Title 47 Part 15.19 (a) (3) - All other devices

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions. (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

1.4 Radio Frequency Emissions Limits in Canada

This device complies with Industry Canada license exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

1.5 USA Public Safety Bands (764–776MHz and 794–806MHz)

The Code of Federal Regulations (CFR) Title 47 Subpart R deals with the use of frequencies in the 764 to 776MHz and 794 to 806MHz bands.

1.5.1 Low-power channels

This radio complies with §90.531 (b) (3) and §90.531 (b) (4) of 47 CFR. These sections state that only low-power transmission is permitted on the following channels:

- Regional Planning channels, as defined in §90.531 (b) (3).
- Itinerant channels, as defined in §90.531 (b) (4).

1.5.2 Use of encryption

This radio complies with §90.553 (a) of 47 CFR. This states that:

- encryption is not permitted on the nationwide Interoperability calling channels. These channels are defined in §90.531 (b) (1) (ii)
- radios using encryption must have a readily accessible switch or control to allow the radio user to disable encryption.

1.6 EMC Regulatory Compliance in Australia



This product meets all ACMA regulatory requirements for electromagnetic compatibility (EMC). For more information about EMC compliance, visit the ACMA website at

www.acma.gov.au.

1.7 Frequency Band Reserved for Distress Beacons

Frequency band 406 to 406.1 MHz is reserved for use by distress beacons. Transmissions should not be made within this frequency band.

1.8 Health, Safety and Electromagnetic Compatibility in Europe

In the European Community, radio and telecommunications equipment is regulated by Directive 2014/53/EU. The requirements of this directive include protection of health and safety of users, as well as electromagnetic compatibility.

1.8.1 Intended purpose of product

This product is an FM radio transceiver. It is intended for radiocommunication in the Private Mobile Radio (PMR) or Public Access Mobile Radio (PAMR) services, to be used in all member states of the European Union (EU) and states within the European Economic Area (EEA).

1.8.2 Restrictions

This product can be programmed to transmit on frequencies that are not harmonized throughout the EU/EEA, and will require a license to operate in each member state.

This product can be programmed for frequencies or emissions that may make its use illegal. Where applicable, a license must be obtained before this product is used. All license requirements must be observed. Limitations may apply to transmitter power, operating frequency, channel spacing, and emission.

1.8.3 Declaration of conformity

Brief Declarations of Conformity appear under [Simplified Declaration of Conformity on page 101](#) of this document. To download the formal declaration of conformity, go to <https://www.taitcommunications.com/our-resources/compliance/declarations-of-conformity>.

1.9 Interference with Electronic Devices



Warning Some electronic devices may be prone to malfunction due to the lack of protection from RF energy that is present when the radio is transmitting.

Examples of electronic devices that may be affected by RF energy are:

- aircraft electronic systems
- vehicular electronic systems such as fuel injection, anti-skid brakes, and cruise control
- medical devices such as pacemakers and hearing aids
- medical equipment in hospitals or health care facilities

Switch off the radio before boarding an aircraft. Using the radio while in the air is not permitted.

Consult the manufacturer (or its representative) of any such electronic devices to determine whether electronic circuits in those devices will perform normally when the radio is transmitting.



Warning If you have a pacemaker:

- immediately turn off the radio if you suspect it is interfering with the pacemaker
- keep the radio at least 6 inches (15cm) from the pacemaker while the radio is on
- use the radio on the side opposite to the pacemaker to minimize interference
- never carry the radio in a breast pocket.

If there is interference between your hearing aid and the radio, please discuss an alternative solution with the hearing aid manufacturer.

1.10 Potentially Explosive Atmospheres and Blasting Areas



Warning Unless the radio is specifically certified for use in a potentially explosive atmosphere, turn off the radio before entering such an atmosphere. An explosion could cause serious injury or death. Examples of potentially explosive atmospheres include filling stations, and any environment where there are flammable liquids, gases, or dusts.



Warning Turn off the radio before approaching blasting caps, a blasting area, or any area where you are instructed to turn off a two-way radio. Obey all signs and instructions. Interference with blasting operations could cause serious injury or death.

1.11 Radio Installation and Operation in Vehicles



Warning Keep the radio away from airbags and airbag deployment areas. Do not install, charge, or place a radio near such areas. An activated airbag can propel a portable radio with sufficient force to cause serious injury to vehicle occupants. An airbag may not perform to specification if obstructed by a radio.



Warning To avoid damage to existing wiring, airbags, fuel tanks, fuel and brake lines, or battery cables, refer to the installation guide for the radio, and to the vehicle manufacturer's manual, before installing electronic equipment in the vehicle.

Using a handheld microphone or a radio while driving a vehicle may violate the laws and legislation that apply in your country or state. Please check the vehicle regulations in your area.

1.12 Vehicle Charger Installation and Operation

For detailed instructions necessary to the safe installation and operation of the vehicle charger, please refer to the documentation supplied with the vehicle charger.

1.13 Multicharger Safety Information



Warning This device must be connected to an earthed mains socket-outlet.

1.14 Electromagnetic Compatibility in European Vehicles

In the European Community, radio equipment fitted to automotive vehicles is regulated by UNECE Regulation R10 Revision 5 and its amendments. The requirements of this regulation cover the electromagnetic compatibility of electrical or electronic equipment fitted to automotive vehicles.

1.15 Unapproved Modifications or Changes to Radio

The radio is designed to satisfy the applicable compliance regulations. Do not make modifications or changes to the radio that are not expressly approved by Tait. Failure to do so could invalidate compliance requirements and void the user's authority to operate the radio.

1.15.1 Attaching of labels



Warning Do not obstruct the vent hole on the battery or the vent hole on the radio chassis label. If the vent on the battery is obstructed, the battery may explode, causing personal injury and/or damage to property. If the vent on the radio is obstructed, audio quality and/or key function may deteriorate and radio seals may be damaged.



Caution Tait recommends that you do not affix additional labels to the surfaces between the radio chassis and the battery. The fit between these surfaces is intentionally firm and any added thickness will damage the points of attachment between radio and battery. If you must attach a customized label, use only a thin gummed paper label applied to the bottom 25% of the radio chassis label and/or to the top 25% of the battery label. Do not obstruct the vent holes (see Warning above). Do not allow the paper label to extend beyond the recessed label area or to conceal relevant product information.

1.15.2 Use of lithium-ion batteries



Warning A damaged battery can cause an explosion or fire, and can result in personal injury and/or property damage. To prevent personal injury and/or damage to property, read the important safety information supplied with the battery.

1.15.3 Short-circuiting battery contacts



Warning Do not short-circuit the battery contacts, neither intentionally nor accidentally, e.g. by placing the battery with conductive materials such as keys or jewelry inside a pocket or container. Short-circuiting the battery contacts can heat up the conductive material and cause personal injury and/or damage to property.

2 Before Using the Radio

2.1 Battery Warning



Warning This radio uses a lithium-ion battery. If the battery is damaged or handled in an unsafe manner, it can cause personal injury and/or damage to property. Read the important safety information included with the battery.

2.2 Attaching Labels to the Radio or Battery



Warning Do not cover the battery vent hole or the vent hole on the radio chassis. If the vent on the battery is obstructed, the battery may explode, causing personal injury and/or damage to property. If the vent on the radio is obstructed, audio quality and/or key function may deteriorate and radio seals may be damaged.




Figure 2.1 Radio chassis and battery vent holes




Figure 2.2 Vent holes in TP9600 Div 1 battery



Tait recommends that additional labels are not applied to the surfaces between the radio chassis and the battery. The fit between these surfaces is intentionally firm and any added thickness will damage the points of attachment between radio and battery.

2.3 Attaching a Label to the Front Panel

If a customer requires an additional label, attach the label in the spare label recess in the bottom surface of the radio front panel. In this position, the label is still visible while the battery is attached to the radio.



Figure 2.3 Spare label recess

Figure 2.4 below shows the specified dimensions of the label.




Figure 2.4 Spare label dimensions



4-key models have a specially designed recess for custom labels.

You can also stick labels over the top of the model label. This recess will accommodate 1/4" label maker labels. Please ensure the labels have a suitable adhesive surface before application.




Figure 2.5 Location of model and custom labels



Tait offers custom labelling for TP9600 P25 Portable Radios. Contact your Tait representative for more information.



No additional labels can be used on TP9600 Div 1 radios.

2.4 Charging the Battery before First Use

Before using the battery for the first time, it must be charged. Follow the instructions included with your Tait charger.



For best charging performance, switch off the radio before placing it in the charger.

2.4.1 Lithium-ion batteries

Fully charge a Li-ion battery before using it for the first time. This will take up to 3 hours. It is not necessary to prime a Li-ion battery.

2.5 Attaching the Battery



Warning Use only genuine Tait-manufactured batteries with Tait radios. Fitting a battery that is not Tait-approved may damage the radio or cause harm.

1. Rotate the power/volume control switch counterclockwise to turn off the radio.
2. Holding the radio firmly, align the back of the battery with the back of the chassis.
3. Place the two lugs at the bottom edge of the battery into the two slots in the bottom of the front panel.
4. Lightly press the top of the battery towards the radio until the battery catch clicks.
5. Make sure that the battery is firmly in position.



If the battery has been attached while the radio is turned on, turn the radio off and then on again before use.

2.6 Removing the Battery



Warning Do not change the battery in a hazardous location. An explosion could cause serious injury or death.

The battery is secured to the radio by a battery catch in the radio's rear panel.

To remove the battery from the radio so that the battery can be charged or replaced:

1. Rotate the power/volume control switch counterclockwise to turn off the radio.
2. Slide the battery catch up.
3. From the sides, pull (tilt) the top end of the battery away from the radio.
4. Lift the lugs at the bottom of the battery upwards out of the mating features at the bottom of the radio body.



If the battery has been removed while the radio is turned on, turn the radio off and then on again before use.

2.7 Attaching the Antenna

Before using the radio, screw the antenna clockwise into the antenna connector. The antenna should be screwed sufficiently tight so that it doesn't unscrew easily. This is important as it creates a seal.

2.8 Removing the Antenna



Warning Do not change the antenna in a hazardous location. An explosion could cause serious injury or death.

Use a firm grip and turn the antenna counterclockwise half a turn. Use a lighter grip to fully unscrew the antenna, and carefully remove it.

2.9 Attaching a Belt Clip

Take the following steps to attach a belt clip to the radio:

1. Slide the belt clip into the two grooves at the top of the battery.
2. Press down on the belt clip until it snaps into place.




Figure 2.6 Attaching a belt clip

2.10 Removing a Belt Clip

The belt clip has been designed to prevent accidental removal, but it can be removed, if required.

Take the following steps to remove a belt clip from a battery:

1. Insert a flat screwdriver blade or similar flat object under the lip of the release lock (that is, between it and the metal slider).
2. Lift the release lock up (away from the metal slider) and hold it in position.
3. Slide the belt clip out.

2.11 Installing an Audio Accessory



Warning Use only Tait-supplied, or Tait-approved audio accessories with Tait radios. Fitting an audio accessory that is not Tait-approved may result in a poor user experience. For an up-to-date list of approved audio accessories, contact your regional Tait office.

Audio accessories plug into the radio's accessory connector. The accessory connector is protected by a cover, which needs to be removed before an accessory can be installed.



The accessory cover protects the accessory connector from electrostatic discharge. Keep the cover in place unless the connector is in use.

2.11.1 Removing the accessory cover

1. Use a coin or other blunt object to loosen the screw that secures the accessory cover to the radio.
2. Remove the accessory cover and store it in a safe place.

2.11.2 Installing an accessory connector

1. Insert the top part of the connector (①) into its designated groove (see [Figure 2.7 below](#)).
2. Press the bottom part of the connector (②) into the pins.
3. Tighten the screw (it only needs to be finger-tight).




Figure 2.7 Accessory connection instructions



Caution Do not slide the accessory's connector along the radio connector's pins; doing so will damage the radio's connector and may prevent a reliable connection to the accessory.




Figure 2.8 Improper connection method

3 Getting Started

This section provides an overview of the TP9600 P25 Portable Radio. It describes the radio's controls and indicators, and explains how the radio menus are organized.

3.1 Setting and Viewing the Radio's Time and Date

The radio may be programmed to use its internal real-time clock. It may be possible to view the time and date via a function key or via the radio menu. Other features may also make use of the radio's time and date by showing entries based on the current clock setting.

3.1.1 Setting the time, date, and time format



The radio may be programmed to allow you to set time and date manually, or time and date can be updated using a GPS source.

1. Press **Menu** and select **Time and Date** and the corresponding option.
2. Follow the prompts on the display.

3.1.2 Viewing the time and date

1. Press **Menu** and select **Time and Date > View clock**



Depending on how the radio is programmed, it may be possible to press a function key to view the time and date.

3.2 About the Radio

TP9600 P25 Portable Radios are available in multiple colors. Radio color does not affect functionality.

TP9600 radios support both digital and analog modes. Differences between digital and analog calls can be noticed in terms of static noise in low signal areas and radio coverage in marginal reception areas.

3.2.1 P25 programming modes

P25 digital radios can be programmed for analog conventional, P25 conventional or P25 trunking operation. In addition, there are dual-mode channels which can receive both analog and digital, and transmit in either analog or digital.


3.2.2 Lack of static noise


On digital networks there is no static noise, even in low signal areas. This lack of static is because the digital radio removes the 'noise' from the call, so that only clear voice is audible.


3.2.3 Active noise cancellation

Active noise cancellation (ANC) uses a secondary microphone to actively filter out background noise in loud and noisy environments. This feature is available in both analog and digital modes. When the radio's internal speaker is being used, a microphone on the back of the radio is utilized as the secondary microphone.

When a wired accessory such as a Remote Speaker Microphone (RSM) is being used, the radio's internal front speaker is utilized as the secondary microphone.

 When using a Bluetooth® audio device, active noise cancellation (secondary microphone) is not enabled. To optimize its performance, Tait recommends positioning the microphone 1 - 2 inches (2.5 - 5cm) from the mouth and speaking directly into it.

 For better performance when using ANC, Tait recommends not covering the rear microphone (on the radio) and the wired accessory (RSM) by your hand or any other accessory.

 Active noise cancellation can be left on regardless of environment. However, for better audio performance, Tait recommends turning it off in quiet areas.

3.2.4 Coverage

With digital networks, a call remains clear and then drops off quickly at the border of a coverage area. The reason for this is that a digital call is either received or it isn't. With analog networks, the background noise in a call gets progressively worse when you are in fringe areas or even slightly outside normal coverage areas.

3.2.5 What is audible on an analog channel

On analog channels, the radio may be programmed so that all conversations on a channel can be heard, or one user group may be segregated from other user groups through special signaling. The special signaling is used to control the muting and unmuting of radios, so that the radio is muted when other user groups are talking and unmuted for members of your user group.

There are two muting controls that operate in the radio:

Signaling mute

The radio's signaling mute only allows the radio to unmute if the incoming call carries the tones specific to your user group. Your user group may use tones that are either audible, subaudible or both.

Squelch

The radio's squelch function allows the radio to unmute only when the strength of the incoming signal is above a predetermined threshold. This means that only signals of reasonable intelligibility are made audible.

3.3 About the Radio Controls

The radio controls and their functions are described in subsequent sections.




Figure 3.1 Radio control functions in TP9600 radios




Figure 3.2 Radio control functions in TP9600 Div 1 radios

Table 3.1 Radio controls

	Name	Function
1	Function keys	As programmed.
2	Status LED	To provide information about the state of the radio.
3	3 way selector	To select frequent functions.
4	Speaker/microphone	Where audio signals are played.
5	Display	Screen that shows menus and messages.
6	Scroll and selection keys	To select a menu option or scroll.
7	Alphanumeric keys	To enter numbers and letters.
8	Push-To-Talk (PTT button)	Press and hold to speak, release to listen.
9	Power/volume control	Turn to the right to switch on or increase the volume. Turn to the left to switch off or decrease the volume.
10	16 way selector	Turn to select channels.














3.4 Understanding the Radio Display








The messages and icons on the radio display depend on the mode in which the radio is operating and the way it is programmed.

3.4.1 Radio display icons

Table 3.2 below lists some of the icons you may see on the radio display:

Table 3.2 Icon descriptions

Icon	Meaning
	Battery indicator: shows how much charge is available in the battery.
	Scanning: the radio is monitoring a group of channels or talkgroups for activity.
	Silent operation: the radio's audible tones have been turned off.
L or L 	Low-power transmit: the radio is set to transmit on low power. When the radio is not transmitting, the letter 'L' is displayed. When the radio is transmitting, a single arrow appears beside the 'L'.
	Transmit: the radio is transmitting.
	Bluetooth Audio Device Connected: there is a Bluetooth audio device connected to the radio. Flashing: the radio is attempting to connect to a Bluetooth audio device, or the device connection has been lost.
	Encryption: the radio's transmissions are encrypted.
	Signal strength indicator: the more bars, the stronger the signal being received by the radio.
	Scrolling: you can use  or  to move through a list, or access a pre-programmed menu.
Trunked mode icons	
	Scanning: scanning has been turned off.
	Homegroup: the radio has been returned to the homegroup using the homegroup toggle function key.

Icon	Meaning
	Trunking system available: the radio is operating on a P25 trunking system.
	'Full' queuing activated: all calls and messages are sent directly to the queue
	Trunking: the radio has established a call and you are now able to speak to the other radio user.
Conventional mode icons	
	Monitor or squelch override: monitor or squelch override is turned on.
	Scanning: the radio is monitoring a group of channels or talkgroups for activity, and the currently selected channel or talkgroup is a member of the scanning group.
	Repeater talkaround: the radio is operating in repeater talkaround mode, or you are on a simplex channel.
	Zone: this letter represents the zone in which the radio is operating, where A is zone 1, Z is zone 26.

3.5 Understanding the Radio Indicators

The status LED indicator and the radio's audible tones - together with the radio display - all combine to provide information about the state of the radio.

The most common way the indicators work is described in the following sections.



The way these indicators behave may be affected by the way the radio is programmed.

3.5.1 Status indicators








Figure 3.3 Location of LED status indicator

Table 3.3 LED indicator types

Color		Meaning
Red (transmit)		Glowing: the radio is transmitting.
		Flashing: the transmit timer is about to expire.
Green (receive)		Glowing: the current channel is busy.
		Flashing: the radio has received a call (analog channel only).

3.5.2 Audible tones

The radio uses audible tones to alert you about its status:

- Radio controls and keypress tones—the tones and beeps that are audible when the radio's keys are pressed or the controls are used.
- Incoming call tone—when the radio is receiving a call.
- Warning tones—for example, when there is an error, or the battery is low.



If quiet or silent mode is turned on, you will not hear any alert tones.

Some of the more common audible tones are described in [Table 3.4 below](#).

Table 3.4 Tones

Tone	Meaning
One short beep	Valid keypress: the action you have attempted is permitted. Function activated: a function has been turned on (using a function key).
One short, low-pitched beep	Function deactivated: a function has been turned off (using a function key).
One long, low-pitched beep	Invalid keypress: the action you have attempted is not permitted. Transmission inhibited: you have attempted to transmit, but for some reason you cannot make a call at this time.
Two short beeps	Radio turned on: the radio is powered on and ready to use. Radio is revived: the radio has been made operable by your service provider.
One short, high-pitched beep	Radio is stunned: the radio has been made inoperable by your service provider.
Two low-pitched beeps	Radio's temperature is high: the radio's temperature is in the high-temperature range, but the radio will continue to operate.
Two high-pitched beeps	Radio's temperature is very high: the radio's temperature is in the very high temperature range and all transmissions will now be at low power; if the radio's temperature rises outside this range, transmissions will be inhibited. Turn off the radio and allow it to cool down.
Continuous low-pitched tone	Radio system error: a system error has occurred and the radio may be inoperable. Contact the radio provider.
Two long high-low pitched tone pairs	Synthesizer out-of-lock: the radio's synthesizer is unstable, causing frequency drift and signal issues, preventing operation on the current channel (display shows "Out of lock"). Contact the radio provider.

3.5.3 Voice annunciation

Your radio may be programmed to play a pre-recorded message for the start-up zone and channel, when changing the zone or channel, for the battery condition, or when loneworker monitoring has been turned on or off.

3.6 Using Function Keys to Access Frequently Used Features

Some keys have functions assigned to both short and long key presses: a short key press is shorter than 1 second, while a long key press is longer than 1 second.




Figure 3.4 Function keys

3.6.1 Viewing the function key settings

Use the Main menu to check the features assigned to the radio’s function keys:

- 1. Press **Menu** and select **Radio settings > Radio info > Key settings**.
- 2. In the **Key Settings** menu, scroll through the list of function keys.
- 3. Press **Select** to view details of the function associated with a particular function key.
- 4. Press **Back** to return to the **Key Settings** menu.

Use [Table 3.5 below](#) to record the function keys programmed for the radio:

Table 3.5 Programmed function keys

	Short key press	Long key press
F1		
F2		
F3		
F4		
F5 ^a		
F6 ^a		

For more information about the function keys that can be programmed on the radio, contact the radio provider.

^aOn speaker microphone (if fitted)

3.7 Navigating the Radio's Menus


The radio has a number of menus, each containing lists or sub-menus. The menus available depend on the way the radio is programmed.

3.7.1 Using the main menu

1. To access the Main menu, press the right selection key whenever **Menu** appears above it.



2. Use the scroll keys to move through the menu list.



3. When the desired menu item is highlighted, press **Select** to open.



The radio may be programmed to use the scroll keys or the left selection key to directly access a menu.

To quickly exit the menu system, press and hold the left selection key when the word **Cancel** or **Back** appears above it.

3.8 Using the Alphanumeric Keys to Search a List

If a blinking cursor appears when you select a list, you are able to search for the menu item you want using the alphanumeric keys. This is of particular benefit if you have a large number of items in a list.

Lists that you may be able to search are channels, zones, talkgroups, and preset calls.

To search a list, type the entire name using the keypad.

3.9 Accessing Frequently Used Menus

Depending on how the radio is programmed, there may be two different Quick Access menus. One Quick Access menu is displayed when a scroll key is pressed, and the other when the left selection key is pressed. These allow easy access to the menus used most often.

3.9.1 Using the scroll key quick access menu

There are two ways to use this Quick Access menu:

- use the scroll keys to scroll through a list of zones or channels
- press the scroll keys and the Quick Access menu appears

3.9.2 Using the left selection key quick access menu

The text above the left selection key corresponds to the Quick Access menu, for example, **Zones**.

To use this Quick Access menu, press the left selection key and the associated menu appears.

4 Basic Operation

This section describes the basic operations of the radio.

4.1 Turning the Radio On and Off

Rotate the power/volume control switch clockwise to turn the radio on. Rotate the switch counterclockwise to turn the radio off.

When the radio is first turned on, the status LED briefly glows red, and the radio gives two short beeps.



The radio may not turn on if its battery voltage is too low.

4.1.1 Security lock on power-up feature

The radio may be automatically locked each time it is powered-up. If the message **Enter PIN** appears on the display, enter your assigned PIN (personal identification number) to unlock the radio.

Locking the radio

1. Press **Menu** and select **Radio settings > Functions > Lock radio**
2. Scroll to either **On** or **Off** and press **Select** (the current setting is highlighted). The radio is now locked, and the message **Enter PIN** appears on the display. The radio remains locked until the correct sequence of keys is pressed. If you forget the unlock sequence or you do not know it, contact the radio provider for assistance.



Depending on how the radio is programmed, you may be able to press a function key to turn radio lock on and off.

4.2 Adjusting the Speaker Volume

Rotate the power/volume control clockwise to increase the speaker volume and counterclockwise to decrease the volume.



The volume control also changes the volume level of the radio's audible indicators.

4.3 Securing the Keypad

The keypad lock feature prevents keys being pressed accidentally. The number of keys that are locked depends on the way the radio is programmed.

4.3.1 Locking or unlocking the keypad

1. Press and hold the right selection key for about one second.



Depending on the radio model and the way it is programmed, the radio may have a 3-way selector that can be used to lock the keypad, or the left selection key can be configured to lock the keypad.

The message **Keypad locked** briefly appears on the display, and **Unlock** appears above the right selection key, in place of **Menu**. When any of the locked keys are pressed, the message **Keypad lock active** appears.

4.4 Holding the Radio

To ensure that effective communication is not hindered:

1. Grip the radio with your hand so that your thumb is on one side, and your fingers are on the other side.
2. Hold the radio vertically in front of your face, angled slightly away, about 1 - 2 inches (2.5 - 5cm) from your mouth.

In this position, the mic and speaker are at the correct distance, and the antenna is facing straight up to maximize range.



Caution Do not hold the radio speaker directly against your ear. This can damage your ear.



Caution Do not pick up or hold a radio by the antenna. This can damage the antenna.

4.5 Speaking into the Radio

Press and hold the PTT button, wait a few seconds, then speak slowly and clearly. Some radios will have a beep, so wait for the beep before you begin speaking.



Push and hold the PTT button throughout transmission. Avoid speaking before pressing the PTT button to prevent cutting off the start of your sentence. Refrain from shouting for clear transmission. Speaking near an active noise-canceling microphone may cancel ambient noise and voice. See [Turning On Active Noise Cancellation on page 45](#) for more details.

4.6 Using a Bluetooth Audio Device

A Bluetooth audio device may be connected to a radio using the **Bluetooth audio device** menu or a function key.



This feature, controlled by a SFE, may not be available with the radio. Active noise cancellation (secondary microphone) is disabled when using a Bluetooth audio device (see [About the Radio on page 28](#) for details). When a menu option is selected in the Bluetooth audio device menu, calls can still be received and replied to without interrupting the selected operation.

4.6.1 Bluetooth audio compatibility with Tait radios

Bluetooth audio devices may operate with Tait radios, provided the accessory is compatible with the Bluetooth Specification Version 2.0 or higher. Tait recommends Bluetooth Specification Version 2.1 or higher. Additionally, the accessory must include Bluetooth Headset Profile (HSP) version 1.1 or 1.2, or Bluetooth Handsfree Profile (HFP) version 1.5 or 1.6.

4.6.2 Wearing the Bluetooth audio device

With a device worn over the head, place it on the ear. Depending on which ear the device is worn, simply adjust the ear hook accordingly.



Ensure that the rear microphone is not covered by your hand or clothing when making a call. This does not apply when using Bluetooth.

4.6.3 Pairing and disconnecting a Bluetooth audio device with the radio



Before attempting to connect a Bluetooth audio device, Tait recommends that the device be fully charged. Refer to the Bluetooth Audio Device installation instructions for charging instructions.

Pairing creates a unique and encrypted wireless link between the Bluetooth-capable radio and the Bluetooth audio device. To use a Bluetooth audio device with a radio, the devices must first be paired.

4.6.4 Pairing a Bluetooth audio device with the radio for the first time

1. Turn on the radio.
2. Put the Bluetooth audio device into pairing mode.
3. Press **Menu** and select **Bluetooth audio device > Find new devices**.

The **New devices** menu opens, and while the radio searches for the new device, the message **Searching ...** appears.

4. Select **Connect** when the required accessory appears in the list of new devices, then click **Yes** to add the Bluetooth audio device to **My Headsets**.

The message **Connecting** appears, while the radio attempts to pair with the device.

5. When the message **Calling. Answer on headset** appears, press the **Answer** button on the Bluetooth audio device to confirm the connection.

6. Repeat the previous steps to add other Bluetooth audio devices.

While the Bluetooth audio device is connected, the Bluetooth audio device icon appears on the display.

4.6.5 Managing your Bluetooth audio devices

Once a Bluetooth audio device has been added to **My Headsets**, the **Manage headsets** menu item appears under the **Bluetooth audio device** menu. The **Manage Bluetooth audio devices** menu shows the devices currently in **My Headsets**, along with the following information:

- **+** this device is currently connected.
- **a** this device will be automatically connected.
- **c** the radio will ask for confirmation before connecting this accessory.

Press **Options** to disconnect or connect a Bluetooth audio device (**Disconnect**, **Connect**), change the priority order of the devices (**Move down**), or remove a device from **My Headsets** (**Remove**, **Remove all**).

4.6.6 Disconnecting the Bluetooth audio device

To disconnect the device from the radio:

- Press **Menu** and select **Bluetooth audio device > Disconnect**.
- Alternatively, in the **My headsets** menu select **Options > Disconnect**.

4.6.7 Reconnecting the Bluetooth audio device

The radio may be programmed so that each time the device is turned on, it will automatically reconnect to the radio. If the radio does not automatically reconnect to the device:

1. On the radio, press **Menu** and select **Bluetooth audio device > Reconnect last**.
The radio then prompts to connect to the devices in **My Headsets**, in priority order.
2. Select **Yes** to connect, or **No** to choose another device.

4.6.8 Changing the way the Bluetooth audio device reconnects

The **Power-on option** in the menu can be used to change the way the radio reconnects with a device when the radio is first turned on. The choices are:

- None: The radio does not connect to any devices, and will need to be manually connected or reconnected to the device.
- Reconnect last: The radio connects to the previously connected device.
- Connect: The radio will attempt to connect to the devices in **My Headsets**, in priority order.

To change the power-on option:

1. Press **Menu** and select **Bluetooth audio device**.
2. Select **Options > Power-on option**.
3. Change to the required setting.

4.6.9 Getting the best performance from the Bluetooth audio device


- Do not block the device's internal antenna (see the device's user documentation). The human body can interfere with a Bluetooth signal.
- If the radio is used with the right hand, wear the over-the-head device on the right ear.
- Avoid coming in contact with the internal antenna of a device or radio.

4.7 Turning On Active Noise Cancellation

Active noise cancellation uses a secondary microphone on the back of the radio to actively filter noise in loud environments, making it easier for recipients to discern the speech of a radio user who is in a noisy environment.


Active noise cancellation can be left on regardless of environment. However, when safety features such as Loneworker Monitoring or Radio Monitor are activated, the listener may lose awareness of the noisy environment. Tait recommends that you implement supplementary procedures to account for this.


The complementary feature of microphone sensitivity allows the internal and external microphones to be configured to suit the type of environment you are in, further improving audio quality. When active noise cancellation is enabled, sensitivity should be decreased. In a quiet environment, increasing the sensitivity is suggested.

 Speaking to the side (nearest the noise canceling microphone) could result in both ambient noise and voice being canceled. To use the radio correctly and achieve the best results, Tait recommends holding the radio 1 - 2 inches (2.5 - 5cm) from the mouth and speaking directly into the front of the radio speaker/microphone.

4.7.1 Turning active noise cancellation on or off

1. Press **Menu** and select **Radio settings > Functions > Noise cancellation**.
2. Scroll to either **On** or **Off** and press **Select**.

 Ensure that the rear microphone is not covered by your hand or clothing when making a call.

 Depending on how the radio is programmed, you may be able to press a function key to toggle active noise cancellation on and off.

4.8 Changing the Radio's Operating Mode

The way the radio performs basic functions, such as sending and receiving calls, depends on the network operating mode. The two operating modes that may be available on the radio are:

- conventional mode (see [Operating on Conventional Channels on page 47](#)) and
- trunked mode.

To change the operating mode:

1. Press **Menu** and select **Change mode**.



Depending on how the radio is programmed, the function key may be pressed to change mode.

2. Select **Yes** to confirm selection, and the radio now shows the default display for either trunked or conventional.

4.9 Limiting Call Time

The radio may limit the amount of time you can talk (transmit) continuously. This is known as the 'transmit timer' or 'time-out timer' and allows other radio users to make calls on that channel.

The message **Transmit Timeout Imminent** appears in the display.

4.10 Checking Recent Calls

This feature is available for digital channels only and applies to individual calls and call alert pages only.

The radio may be able to store a list of the last 20 calls. These calls may be calls that have been received, calls that have been made, or calls that have been missed.

To use the recent calls list to make a call:

1. Press **Menu** and select **Recent calls**.

The most recent call is displayed at the top of the list. If you have not participated in any calls since the radio was switched on, the message **No items in list** appears in the display.

The radio's behavior depends on the mode the radio is set to. See [Making an individual call on page 53](#) for more information.

5 Operating on Conventional Channels

This section covers operations on conventional channels, beginning with analog functions, followed by P25 operations before concluding with an explanation on how the radio functions in different repeater areas.


5.1 Analog Channel Operation Only

5.1.1 Setting your status

The radio may be able to maintain a record of its current status. This status may be sent with outgoing calls programmed to contain status information. If the radio receiving the call has been programmed with the same status messages, it will decode and display its status. The status indicates the current activity or location, such as “en route” or “at lunch”.

Changing the current status

1. Press **Menu** and select **Set status**.



2. In **Set status** menu, scroll through the list of status messages until the desired message appears.
3. Press **Select**. The message **Status updated** appears on the display.

5.1.2 Resending calls automatically

On an analog channel that is configured for SelCall/5-Tone operations, the radio may have been programmed to resend individual and group calls when transmission is refused because the channel is busy.

There are two automatic callback features: 'Deferred calling' and 'No acknowledgment retries'.

Deferred calling

On an analog channel that is configured for SelCall/5-Tone operations, when attempting to make a call on a channel that is busy, the radio can store and send the call once the channel is free. The radio gives a low-pitched beep if the channel is busy, and then waits until the channel is free to retry the call.



A deferred calling time limit may have been configured. Once the time limit has expired the radio will no longer attempt to retry the call. Any user interaction (such as pressing the PTT button) will cancel a deferred call.

No acknowledgment retries

On an analog channel that is configured for SelCall/5-Tone operations, when you send a call and there is no reply, the call is resent.

Any user interaction (such as pressing the PTT button) will cancel a call that is being resent.


5.1.3 Bypassing the repeater and communicating directly with other radios

For analog channels, you can bypass the radio repeater and communicate directly with another radio. This feature is known as repeater talkaround. This can be done, for example, when you are out of range of the repeater, or if the repeater is busy or stops working. While repeater talkaround is active, all transmissions are made on the receive frequency of the channel you are on.


There are two ways to activate repeater talkaround:

- using the main menu
- using a programmed function key

Using the main menu

1. Select the required channel.
2. Press **Menu** and select **Radio settings > Functions > Talkaround**.
3. In the **Talkaround** menu, choose **On**.
4. Press **Select**. The message **Talkaround activated** appears briefly, and the repeater talkaround icon  appears on the display.
5. Proceed with the call.
6. To turn repeater talkaround off, either change the channel, or choose **Off** in the **Talkaround** menu.

Using a programmed function key

1. Select the required channel.
2. Press the programmed function key to turn repeater talkaround on. The message **Talkaround activated** appears briefly, and the repeater talkaround icon  appears on the display.
3. Proceed with the call.
4. To turn repeater talkaround off, either change the channel, or press the function key again.


5.2 P25 Channel Operations

5.2.1 Selecting a zone

The radio may be programmed to use zones, which are collections of channels and groups. Zones are a way of grouping channels, for example, by public safety agency type (fire, police, ambulance, etc) or by geographical region (Dallas, Houston, etc). When a zone is selected, only the channels and groups assigned to that zone are available.


Using the main menu

1. Press **Menu** and select **Zones**.



Depending on how the radio is programmed, scroll keys or left selection keys may be used to select the **Zones** menu.

2. In the **Zones** menu, scroll through the list of zones until the desired one appears.



3. Press **Select**, and the zone indication appears either below the channel information, beside the RSSI icon, or in both positions. These can also be set to not be displayed.

The following controls may also be used to select a zone:

- left selection key
- scroll keys
- function keys to scroll through zones
- 3-way selector




If the 3-way selector is turned while pressing the PTT button, the zone will change after the PTT button is released.

5.2.2 Selecting a channel


Using the main menu

1. Press **Menu** and select **Channels**.



Depending on how the radio is programmed, the scroll keys, the left selection key, or a function key may be used to select the **Channels** menu.

2. In the **Channels** menu, scroll through the list of channels until the desired channel appears.



3. Press **Select**, and the programmed channel is now shown on the display.

Using the scroll keys

The radio may be programmed to use the scroll keys to scroll through the channels.

Using the channel selector

The channel selector can be used to select 16 channels.

If the channel selector is turned while pressing the PTT button, the channel will change after the PTT button is released.


Using the keypad



This feature is only available for radios with alphanumeric keys.

Dialing a channel may be available from the radio's idle display but is always available while in the **Channels** menu.

1. Dial the number associated with the channel using the alphanumeric keys.



To delete a digit that you have dialed incorrectly, press **Clear**.

2. Press **Select** or #, and the programmed channel is now shown on the display.

Automatic channel selection

The radio may be configured to change channels automatically based on current location.

The automatic mode icon **A** will be visible on the display.

Selecting a channel manually as described above will end automatic mode, and the manual mode icon **M** will appear on the display.

The radio may be configured to use a timer or a function key to return to automatic mode.

Using the numeric keypad to store and recall channels

Channels may be stored and recalled using the numeric keypad.

- long-press a numeric key to store the current channel
- short-press a numeric key to recall the stored channel

Only one channel can be stored and recalled for each numeric key.

The following controls may also be used to select a channel:

- function key
- left selection key
- scroll keys

5.2.3 Understanding talkgroups



This section applies to P25 trunked only. It does not apply to P25 conventional.

A talkgroup is a collection of radio users who can have private conversations. For example, a state's public safety agencies could have the following talkgroups:

- Local talkgroups: used by a specific agency to communicate within their own local agency. It may even be made up of a county of public safety officers.
- Regional talkgroups: used by large state agencies that have regional divisions.
- Statewide talkgroups: used by an agency to communicate with public safety members in other regions (such as counterparts across entire states).
- Special event talkgroups: may be used to manage emergencies encompassing a large area, or even events such as visits by heads of state.

You can not create Talkgroups, they are configured during set up.

5.2.4 Making a call





Ensure that the rear microphone is not covered by your hand or clothing when making a call.

1. Select the required zone (see [Selecting a zone on page 49](#)).
2. Select the required channel (see [Selecting a channel on page 50](#)).
3. Hold the radio so that the microphone is about one inch (2.5cm) from your mouth and press the PTT button to transmit.
4. Speak clearly into the microphone and release the PTT button when you have finished talking.
5. Finish the conversation as soon as possible and release the PTT button. For a short time, the radio may prevent you from making another call.

If the channel is busy, you may not be able to transmit. Wait until the status LED has stopped glowing green, and then try again.



While transmitting, the LED glows red and the transmit, , or low power transmit, , icon appears on the display.

Limiting call time

the radio may limit the amount of time you can talk (transmit) continuously. This is known as the 'transmit timer' or 'time-out timer' and allows other radio users to make calls on that channel.

The message **Transmit Timeout Imminent** appears on the display. If the transmit timer has timed out, you must release the PTT button before you can transmit again.

The radio may be configured with a lockout time which prevents you from immediately starting a new transmission after the transmit timer has timed out.

Utilizing active noise cancellation when making a call

Background noise can be filtered out in loud and noisy environments by turning on Active Noise Cancellation before a call. For more information, see [About the Radio on page 28](#).

Making an individual call

This feature is available for digital channels only. For analog individual calls, see [Making a local call below](#).

When making a call to one person:


- Press **Menu** and select **Individual call**.
- Scroll to the desired person to call and press the PTT button to make the call immediately.
Alternatively, press **Call** and then the PTT button.

Making a local call

For analog channels, each channel on the radio may have one or more local calls programmed. For digital radio-to-radio calls, see [Making an individual call above](#).



Making a call using the main menu

1. Select the required channel.
2. Press **Menu** and select **Local calls**.



3. In the **Local calls** menu, scroll through the list of local calls until the desired call appears.
4. Press **Send**.



The call details appear on the display, the LED glows red, and the transmit , or low power transmit , icon appears on the display.

Making a call using the quick access menu


1. Select the required channel.
2. Press one of the scroll keys or the left selection key to open the **Local calls** menu.
3. Scroll through the list of local calls until the desired call appears.
4. Press **Send**.

Dialing a local call

1. Select the required channel.
2. Press **Menu** and select **Dial radio call**.
3. Dial the number using the alphanumeric keys.
4. Press **Send** (if the Send option appears).


The radio may be programmed so a local call can be dialed directly from the default display. In this case, the call can be dialed without selecting the menu option.

The radio may be programmed so group tones can be dialed using the * and # keys. Dial * to fill one **X**. Dial # to fill the current **X** and all subsequent **X** characters in the current burst.

When you receive a call, the LED glows red and the call details plus  appears on the display. The message **Ack received** may also appear.

Dialing a radio call

To dial a call to another radio, or group of radios:

1. Select the required channel.
2. Press **Menu** and select **Dial radio call**.
3. Dial the number using the alphanumeric keys. For analog calls, press **Send**.
4. The call details appear on the display, the LED glows red, and  appears on the display.

The radio may be programmed so a call can be dialed directly from the default display. In this case, it's possible to start dialing the call without selecting the menu option.

On an analog channel using SelCall/5-Tone Network setup, you may encounter **X** and **S** characters, prompting you to dial over them. When the called party responds to the call, the message **Ack received** may display. Additionally, on the same analog channel, the radio can be programmed to utilize group tones by pressing the asterisk (*) or hash (#) keys. Dialing

asterisk (*) fills one **X**, while hash (#) fills the current **X** and all subsequent **X** characters in the current burst.

Making an emergency call

You may be able to activate emergency mode by using a programmed function key.


During emergency mode, the radio automatically cycles between receive and transmit for dispatcher monitoring. It deactivates after a set duration, or can be instantly canceled by pressing the function key again if it is enabled as a toggle.

1. Press the function key programmed for Emergency Mode and an emergency call is sent to the dispatcher, or some other predetermined location.
2. Reset the radio to normal operation at any time by turning the radio off and then on.

5.2.5 Making a phone call or DTMF patch call

A telephone network can be directly connected to by manually dialing the number or using preset dialing sequences if the network is configured to support phone calls.

1. Select the required channel.
2. Press **Menu** and select **Phone call**.
3. Press **Call**.

The call details appear on the display, the LED glows red, and  appears on the display.

Using a function key



Depending on how DTMF patch calls are programmed, some of the following steps may not be necessary.

1. Select the required channel.
2. Press the function key programmed for DTMF patch call (the radio may send tones to capture the line).
3. Press **Send**, or press the function key a second time, to send the preset number (there may be telephone dialing and ringing tones).
4. Proceed with the call.
5. Press **End**, or give a long press on the function key, to end the call (the radio may send tones to release the line).

Using the main menu

1. Select the required channel.
2. Press **Menu** and select **Dial patch call**.
3. Dial the required number using the alphanumeric keys.
4. Press **Send** (the radio may send tones to capture the line).

5. Press **Send** to send the number dialed in step 3 (there may be telephone dialing and ringing tones).
6. Once the call has finished, press **End** (the radio may send tones to release the line).

Dialing DTMF tones (overdialing)

The radio may be programmed to allow dialing of DTMF tones using the numeric keypad while on a channel or in a call. The dialing may be either sent out immediately (as it's typed) or sent after pressing **Send**.

5.2.6 Call alert

You can let other radio users know that you wish to communicate by sending them a call alert page. When the other radio user receives the call alert page, they can call back when it is convenient.

Sending a call alert page

1. Press **Menu** and select **Services > Call alert**.
2. Select the desired radio to page.
3. Press **Send to**.

A message showing the radio destination appears on the display. The LED glows red, and a notification indicates whether the message was sent successfully.

If an acknowledgment is not received from the recipient's radio, you will have the option of either canceling or resending the request.

Answering a call alert page

If a call alert page is received from another radio user, **Call alert** and the caller name appears onscreen.

Select **Call** to return the page or **Clear** to delete it. If the call alert page is missed, a call alert entry is added to the queue.

5.2.7 Bypassing the repeater

This function applies to both Analog and P25 channels. For detailed information on this feature, see [Bypassing the repeater and communicating directly with other radios on page 48](#).

5.2.8 Sending and receiving a status message

A status message is sent to another party to indicate current activity or location, such as "en route" or "at lunch". If the radio receiving the message has been programmed with the same status messages, it will decode and display the message. If a status message is received, the message is automatically queued, since a response is not expected. Status messages can also be used to control external devices.

Sending a status message

1. Press **Menu** and select **Services > Status update**.
2. In the **Status update** menu, scroll through the list of status messages until the desired message appears.
3. When a message has been chosen, press **Select**.

Depending on how radio is programmed, the message may be sent directly to a pre-configured radio or group, or you will be presented with options to select a destination.

The call details appear on the display.

Receiving a status message

1. Press **Options** and select whether to reply, call or delete.

If the radio is programmed for call queuing, incoming status messages are added to the queue. For more information,

The radio may be programmed to automatically view status messages on receipt.

If the radio is not programmed for call queuing, incoming status messages are displayed briefly.

5.2.9 Radio inhibit and uninhibit

When a radio is immobilized ('inhibited'), the encryption keys may be automatically deleted from the radio.

This feature is only available for digital channels operating in conventional mode, and for radios configured for dispatcher operation.

If you want to make another radio on the system inoperable, you can use the radio inhibit feature. This feature is also known as 'stun'.

To the user of the inhibited radio, it appears as though the radio has turned off. The radio remains inoperable even if it is turned off and then on again.

The radio cannot return to operation until it receives an uninhibit request. This is also known as 'revive'.

Sending a radio inhibit request

1. Press **Menu** and select **Services > Radio inhibit**.
2. Scroll to the desired radio to make it inoperable.
3. Press **Send to**.

The LED glows red, and a message appears on the display indicating the radio has been successfully immobilized.

Sending a radio uninhibit request

1. Press **Menu** and select **Services > Radio uninhibit**.
2. Scroll to the radio to be made operable.

3. Press **Send to**.

If the radio has been successfully returned to operation, the uninhibited radio will briefly display **Radio revived**.

If an acknowledgment is not received from the recipient's radio, you will have the option of either canceling or resending the request.

5.2.10 Radio monitor

The radio unit monitor feature can be used when concerned about the safety of a radio user on the same P25 conventional channel. When sending a radio-unit monitor request to a radio, it calls the user back without giving any indication that it is making a call. You can hear any activity near the radio for up to 120 seconds.

Sending a radio unit monitor request

1. Press **Menu** and select **Services > Radio monitor**.
2. If an address book is configured, it is possible to select to either dial a number or show the address book. Otherwise a preset list of radios will appear.
3. Scroll to the radio to be monitored.
4. Press **Send to**.

A message showing the radio destination appears on the display. The LED glows red, and a notification indicates whether the message was sent successfully.

If the other radio has received your request, it will now call you, so that you can monitor activity near the radio.

If an acknowledgment is not received from the recipient's radio, you will have the option of either canceling or resending the request.



If Active Noise Cancellation is turned on, you may not be able to hear any background noise.

5.2.11 Transmitting at low power

When low power transmit is turned on, a notification appears on the display and calls are made at low power rather than at the programmed power setting.

Some channels may always transmit at low power.

Using the main menu

To turn low power transmit on or off for all channels, see the following:

1. Press **Menu** and select **Radio settings > Functions > Low power tx**.
2. Scroll to **On** (or **Off**) and press **Select**.


The current setting is highlighted.

The message **Low power tx activated** (or **deactivated**) appears on the display.

Using a function key

1. Press the function key programmed for low-power transmit to transmit at low power on your current channel and any channels subsequently used.




The message **Low power tx activated** appears briefly, and the low-power transmit icon **L** or **L**  appears on the display.

When the radio is not transmitting, the letter 'L' is displayed. When the radio is transmitting, a single arrow appears beside the 'L'.

2. Press the low-power transmit function key again to turn low-power transmit off, and the message **Low power tx deactivated** appears on the display.

5.3 Using the Radio in Different Repeater Areas

The radio may have a group of channels programmed as a voting group. The channels in the voting group all carry the same traffic, but from different repeaters. As the radio moves in and out of different repeater coverage areas, the best communication channel is automatically selected for use.

This channel is known as the 'home' channel, and will be the channel used to make and receive calls. While voting is active, the scanning icon  appears on the display.

5.3.1 Selecting a voting group

Using the channel selector

You can use the channel selector to select a preset voting group. If the radio is programmed in this way:

- rotate the channel selector to the group you want.

Using a function key

To use a function key to select a voting group:

- press the function key to select and activate a preset voting or scanning group.

Using the main menu

To select a voting group using the Main menu:

1. Press **Menu** and select **Channels**.
2. Scroll to the group you want and press **Select**.

5.3.2 Suspending a channel from a voting group

You may be able to use the function key programmed for nuisance delete to temporarily delete one of the channels from the voting group.

When that voting group is next selected, or after the radio has been turned off and then on, the deleted channel is again part of the voting group.

Alternatively, the function key programmed for voting may be programmed so that a short key press turns on voting, and a long key press activates nuisance delete.

- Press and hold the function key programmed for voting to remove the current channel from the voting group.

If the operation has been successful, the message **Channel nuisance deleted** appears on the display.

6 Operating on P25 Trunking Networks

This section explains how to operate your radio on a P25 network (trunked and conventional) network. This includes how to make group calls, individual calls, and phone calls.



This feature is controlled by a software license (SFE) and may not be available with your radio by default.

6.1 About P25 Trunking

The radio may be able to operate on a P25 trunking system as well as a conventional repeater-based system. On a conventional system, radio users compete for access to individual channels, and one channel can be overloaded with traffic while others are often unused.


The trunking system allows several channels to be automatically shared by a number of radio users. These traffic channels are pooled and allocated, as required, for the duration of a call. As calls are completed, the traffic channels are returned to the pool, to be used for other calls. This system means reduced waiting times to make calls.

6.2 Checking that the System is Available

When you first switch to a talkgroup configured for P25 trunking, the radio attempts to access the network and register on a control channel.



If registration is successful, the trunking system available icon, , appears in the display.

6.2.1 Registration is unsuccessful

If registration is not successful,  does not appear, and the display shows **No service**.

The radio may sound five beeps, followed by a repeating double beep. The double beep continues until registration is successful.

6.2.2 Service is lost

If access to the trunking system is lost,  no longer appears, the bars in the RSSI icon disappear , and the display shows **No service**.

The radio sounds five beeps to indicate the loss of service, followed by a repeating double beep. The double beep continues until service is restored.

6.2.3 Site trunking operation

During normal trunking operation, the radio may roam between a number of sites. This behavior is transparent to you, unless there is a problem with a system controller. When this happens, the radio enters 'site trunking' mode, and you will only be able to communicate with other users within a single site.

While in site trunking mode, the display shows **Site Trunking**, and the radio sounds a repeating double beep. The double beep continues until normal service is restored.

When access to the zone controller is available again, the radio automatically returns to normal multi-site operation.

6.2.4 P25 phase 2 fallback mode

If there is a fault on the phase 2 network, operation may fall back to phase 1 mode.

6.2.5 Failsoft operation

The radio may be programmed to enter 'failsoft' mode when service is lost due to failure of a trunking site controller. For more information, see [Failsoft Mode Operation on page 95](#).

6.3 Making a Talkgroup Call



Ensure that the rear microphone is not covered by your hand or clothing when making a call.


A talkgroup is a collection of radios on a trunking system. Trunked talkgroups are found in the Channels menu, along with conventional channels that may also be available for the currently selected zone.

Depending on how the radio is programmed, you may be able to press a function key, use the Quick Access menu or use the channel selector to select a trunked talkgroup.

In some situations, the call will not proceed. For an explanation of the radio behavior, see [Unconnected Calls on page 96](#).

6.3.1 To make a talkgroup call on a trunking system

1. Select the required zone:
 - Press **Menu** and select **Zones**.
 - Scroll to the required zone, and press **Select**.



Depending on how the radio is programmed, you may be able to press a function key to access the Quick Access menu or use the 3-way selector to select a zone.

The radio can be configured to indicate the zone in which it is operating, either as a letter in the top right corner of the display, or as a zone name in the second line of the display, or neither.



2. Select the required talkgroup:
 - Press **Menu** and select **Channels**.
 - Scroll to the required talkgroup, and press **Select**.



Depending on how the radio is programmed, you may be able to press a function key, to access the Quick Access menu or use the channel selector to select a talkgroup.

3. To call this talkgroup, hold the radio so that the microphone is about one inch (2.5cm) from your mouth.
4. Press and hold the PTT button to transmit.
5. When you hear three short beeps, speak clearly into the microphone. Release the PTT button when you have finished talking, and the radio will indicate the currently selected talkgroup.



While transmitting the LED glows red and the transmit  or low power transmit  icon appears in the display.

6.4 Utilizing Active Noise Cancellation when Calling a Talkgroup

Background noise can be filtered out in loud and noisy environments by turning on Active Noise Cancellation before calling a talkgroup. For more information, see [About the Radio on page 28](#).

6.5 Receiving a Talkgroup Call

To hear calls from other members of a talkgroup, the radio must have the specific talkgroup selected, or the talkgroup must be a part of an active scanning group.

For information about selecting a talkgroup, see [Making a Talkgroup Call on page 62](#), and for information about talkgroup scanning, see [Activating Talkgroup Scanning on page 77](#).

When you receive a call from a talkgroup, the radio displays the name or the identity of the talkgroup, and that of the calling radio.

6.6 Making an Individual Call

In some situations, your call will not proceed. For an explanation of the radio behavior, see [Unconnected Calls on page 96](#).

6.6.1 To make a call to one radio on a trunking system

1. Press **Menu** and select **Individual call**.



Depending on the radio model and how it is programmed, you may be able to dial the identity of the radio you want to call, press a function key or use your Quick Access menu to select an individual call.

2. Scroll to the person you want to call and press **Select** or press the PTT button.
3. The message **Calling...** briefly appears.
4. When the called party accepts the call, you will hear three short beeps.
5. Once the called party has finished talking, press and hold the PTT button to transmit, speak clearly into the microphone, and release the PTT button when you have finished talking.

6.7 Utilizing Active Noise Cancellation when Making an Individual Call

Background noise can be filtered out in loud and noisy environments by turning on Active Noise Cancellation before a call. For more information, see [About the Radio on page 28](#).

6.8 Receiving an Individual Call

When you receive a call from an individual radio, the radio displays the caller's name or identity.

The radio rings until the call is answered.

1. Press the PTT button to accept the call, or **Cancel** to reject the call.

6.9 Emergency Calls

In an emergency, you can summon help by sending an emergency call. When an emergency call is initiated, the radio enters 'emergency mode'.

6.9.1 Making an emergency call

You can make an emergency call using the emergency function key (function key 1):

1. Press the function or emergency key to activate emergency mode.

The message **Emergency mode** appears and the radio sounds three short beeps, rising in pitch.

6.9.2 Receiving an emergency call

When you receive an emergency call, the radio displays the caller's name or identity and sounds a long beep.

6.10 Making a Phone Call

You may be able to use the radio to connect to a telephone network and make a phone call. In some situations, your call will not proceed. See [Unconnected Calls on page 96](#).

6.10.1 To make a phone call on a trunking system

1. Press **Menu** and select **Phone call**.

The number you last dialed appears in the display, unless that number was manually dialed.

2. Scroll to the number or person you want to call or dial the required number using the alphanumeric keys.
3. Press **Select** or the PTT button.

Call progress will be indicated by **ring** or **busy** tones as for a standard telephone call.

4. When the call is answered, proceed with your conversation.
5. At the completion of the call, or if the dialed number is busy or does not answer, press the **End** left selection key.

6.11 Dynamic Regrouping

The dynamic regrouping feature allows you to send a dynamic regrouping request to the dispatcher. The dispatcher can then reassign your radio to a special communications group.



Normal channel selection may be disabled while operating on this group.

6.11.1 To send a dynamic regrouping request

- Press **Menu** and select **Trunking > Dyn Regrouping**.

When **Select** is pressed, 'Sending dynamic regroup rqst' appears in the display.

If the request is successful, an acknowledgment message is displayed.

7 P25 Services

This section describes the P25 services that are available on the radio.



This feature is controlled by a software license (SFE) and may not be available with the radio by default.

7.1 P25 Emergency Operations

This section describes how to make different types of emergency calls on P25 channels.

7.1.1 About emergency calls



Warning The radio can be configured to automatically delete ("zeroize") encryption keys when emergency mode is activated.

In an emergency you can summon help by sending an emergency call. [Table 7.1 below](#) lists the types of emergency calls:

Table 7.1 Types of emergency calls

Call type	Explanation
Priority call	Priority call applies to digital channels only. An emergency alert is automatically sent to the current talkgroup when the priority call feature is turned on. Calls made with this feature activated are flagged as 'emergency' calls. For further information, see Making a priority call on the next page .
Standard emergency call	When an emergency call is initiated, the radio enters 'emergency mode'. For further information see Standard emergency mode on the next page .
Manual emergency call	Manual emergency call applies to digital channels only. When activated, the emergency mode is triggered and the radio sends an alert to the dispatcher and other group members, including the radio's digital alias and location. For further information, see About manual emergency operation on page 69 .

7.1.2 Making a priority call



This feature is available for digital channels only.

When you turn the priority call feature on, the radio automatically sends an emergency alert (message) to the current talkgroup.

Any calls you make while the priority call feature is turned on are flagged as emergency calls.

Turning the priority call feature on and off

1. Press **Menu** and select **Priority call**.
2. Scroll to **On** (or **Off**) and press **Select**.

7.1.3 Standard emergency mode

When you press the emergency key the radio enters 'emergency mode', if the radio is programmed in this way.

When the radio enters emergency mode, it will automatically send alerts together with the radio unit ID to the dispatcher. These alerts are usually sent on a designated emergency channel.

What happens during an emergency call?

The exact way the radio behaves when it enters emergency mode depends on how it is programmed.

The main phases for emergency modes are summarized below. The length of each phase is determined when the radio is programmed.

When the emergency key is pressed

1. **Digital Channels:** The radio continually sends emergency alerts to the dispatcher until a response is received. Details of your location may also be sent (if this feature is available for the radio).
2. The radio alternately transmits and receives so the dispatcher can hear what is happening in the vicinity of the radio. Emergencies end once this phase is complete or when emergency mode is ended.

Activating emergency mode

You can activate emergency mode using the emergency function key.

1. Press the function or emergency key to activate emergency mode.



How emergency mode is activated depends on how it has been configured. Confirm this step with your administrator.

One or more emergency calls are sent to your dispatcher or another predetermined radio user. During emergency mode, the radio will behave as described in [What happens during an emergency call? on the previous page](#).

2. To end emergency mode and return the radio to normal operation, either:
 - turn the radio off and on again to end emergency mode,
 - push the function or emergency key again, or
 - if configured, press the PTT button

7.1.4 About manual emergency operation



This feature is available for digital channels only.

When you press the emergency key, the radio sends an alert to your dispatcher and other members of your group, along with the radio digital alias and location.

While the emergency call is active, the emergency information is sent out periodically, until either you or another member of your group end the emergency call.

You are still able to make and receive voice calls while emergency information is being sent, but the radio does not display caller details.

Making a manual emergency call

You will not be able to make a voice call on the channel until the 3-second emergency alarm has finished.

1. Press and hold the emergency key for longer than three seconds.



How emergency mode is activated depends on how it has been configured. Confirm this step with your administrator.

2. The radio gives three short beeps, rising in pitch.
3. **Emergency** appears in the display, and remains until the manual emergency call is canceled.

If you receive an acknowledgment from another radio in your group, the manual emergency call is canceled, and the message **Emergency Acked** briefly appears in the display.



This feature is controlled by a software license (SFE) and may not be available with the radio by default.

Canceling a manual emergency call

If the emergency situation has been resolved, the manual emergency call can be canceled either by you or another member of your group.

1. Press and hold the emergency key until the message **Emergency canceled** appears in the display.

The radio now returns to the channel that it was operating on prior to the emergency call.

Canceling a manual emergency call you have received

When you have received a duress emergency call, the Emergency menu always moves to the top of the menu list. In the Emergency Menu, you can manually acknowledge the duress emergency call. This acknowledgment cancels the call.

1. Press **Menu** and select **Emergency > Acknowledge**.

The name of the radio that initiated the emergency call appears in the display.

2. Press **Send** to cancel the manual emergency call from that number. The message **Emergency ack. sent** briefly appears in the display.

7.1.5 Accessing emergency location information

If **Location** appears in the display, above the left selection key, you can display the current location of the radio that has sent a manual emergency call. The last location of the radio will still be available even if the radio is turned off and then on again.

To access the location information, either press **Location** or use the **Last Stored** menu.

Using the location menu

1. Press **Location** to display the current location of the radio.
2. Use the scroll keys to view more location information.
3. Press **Exit** to return to the previous display.

Using the last stored menu

1. Press **Menu** and select **Emergency > Last stored** to display the current location of the radio.
2. Use the scroll keys to view more location information.
3. Press **Exit** to return to the previous display.

7.2 Call Alert

You can let another radio user know that you want to talk to them by sending them a call alert page. When the other radio user receives the call alert page, they can call you back when it is convenient.

- If you are on a P25 trunked channel, you can send a call alert to any other radio on a trunk channel on the same network.
- If you are on a P25 conventional channel, you can send a call alert to any other radio on the same conventional channel.

7.2.1 Sending a call alert page

1. Press **Menu** and select **Services > Call alert**.
2. Select the radio you want to page.
3. Press **Send to**.

A message showing the radio destination appears on the display. The LED glows red, and a notification indicates whether the message was sent successfully.

If an acknowledgment is not received from the recipient's radio, you will have the option of either canceling or resending the request.

7.2.2 Answering a call alert page

If you receive a call alert page from another radio user, the message **Page rx'd from...** briefly appears in the display.

Select **Call** to return the page or **No** to delete it. If you miss the call alert page, the identity of the caller may be saved in your recent calls list.

7.3 Messages

You may be able to send short messages to another radio user. These messages are defined at programming time.

- If you are on a P25 trunked channel, you can send a message to any other radio on a trunk channel on the same network.
- If you are on a P25 conventional channel, you can send a message to any other radio on the same conventional channel.

To read and display a sent message, receiving radios must have the same message programmed.

7.3.1 Sending a message

You may be able to send your message to a predetermined person or to the dispatcher administering the current talkgroup, or to a person of your choice.

Sending a message to a predetermined person or talkgroup administrator

1. Press **Menu** and select **Services > Messages**.
2. Select the required message from the list.
3. Press **Select**.

A message showing the radio destination appears on the display. The LED glows red, and a notification indicates whether the message was sent successfully.

If an acknowledgment is not received from the recipient's radio, you will have the option of either canceling or resending the request.

Sending a message to a person of your choice

1. Press **Menu** and select **Services > Messages**.
2. Select the required message from the message list.
3. Press **Select**.
4. Select the message recipient from the list and press **Send to**.

If an acknowledgment is not received from the recipient's radio, you will have the option of either canceling or resending the request.

7.4 Radio Check



This feature is only available on P25 conventional channels.

If you want to find out whether a particular radio is available on the system, you can use the radio check feature. This sends a radio check message to the radio unit you have specified.

1. Press **Menu** and select **Services > Radio check**.
2. Scroll to the radio you want to check.
3. Press **Send to**.

A message showing the radio destination appears on the display. The LED glows red, and a notification indicates whether the message was sent successfully.

If the radio is available on the system, an acknowledgment message is displayed.

If an acknowledgment is not received from the recipient's radio, you will have the option of either canceling or resending the request.

7.5 Radio Unit Monitor



This feature is controlled by a software license (SFE) and may not be available with the radio. This software license is only required for the radio that sends the radio unit monitor request. The receiving radio does not need the software license.

This feature is only available for digital channels operating in conventional mode, and for radios configured for dispatcher operation.

The radio unit monitor feature ensures user safety by silently calling back the sender, allowing them to listen to nearby activity for up to 20 seconds.



If Active Noise Cancellation is turned on, you may not be able to hear any background noise.

7.5.1 Sending a radio unit monitor request

1. Press **Menu** and select **Services > Radio monitor**.
2. Scroll to the radio you want to monitor.
3. Press **Send to**.

A message showing the radio destination appears on the display. The LED glows red, and a notification indicates whether the message was sent successfully.

If the other radio has received your request, it will now call you so that you can monitor activity near the radio.

If an acknowledgment is not received from the recipient's radio, you will have the option of either canceling or resending the request.

7.6 Status Request



This feature is only available on P25 conventional channels.

You can find out what another radio user is currently doing by asking their radio to send you a status update.

7.6.1 Sending a status request

1. Press **Menu** and select **Services > Status request**.
2. Select the status request recipient from the list.
3. Press **Send to**.

A message showing the radio destination appears on the display. The LED glows red, and a notification indicates whether the message was sent successfully.

If an acknowledgment is not received from the recipient's radio, you will have the option of either canceling or resending the request.

7.7 Status Update

You can inform another radio user of your current status by sending them a status update, for example, 'At scene'. You may be able to send the status update to a predetermined person or talkgroup, or to a person of your choice.

- If you are on a P25 trunked channel, you can send your status to any other radio on a trunk channel on the same network.
- If you are on a P25 conventional channel, you can send your status to any other radio on the same conventional channel.

When you send a status message, you are also *setting* your status, which the dispatcher may be able to check by 'interrogating' the radio. You can change your status at any time by selecting another status message and sending it. See [Status Request on the previous page](#).

7.7.1 Sending a status update

1. Press **Menu** and select **Services > Status update**.
2. Select the required status message from the list.
3. Press **Send to** or **Select**.

A message showing the radio destination appears on the display. The LED glows red, and a notification indicates whether the message was sent successfully.

If an acknowledgment is not received from the recipient's radio, you will have the option of either canceling or resending the request.

To set a status without sending it to anyone, see [Setting your status on page 47](#).

8 Scanning


This section explains the different types of scanning that are available on the radio, and also how to view and edit scanning group members.





The features described in this chapter are for P25 conventional/trunked/analog channels only.

8.1 About Scanning

The scan feature monitors groups of channels or talkgroups for activity, allowing operation across multiple channels or talkgroups simultaneously. For example, you can monitor your dispatch channel and local sheriff and highway patrol channels. Scanning groups can include conventional channels (P25 or analog), trunked talkgroups, and vote groups. When scanning, the radio searches for activity among the group members. If activity is detected, the radio stays on that channel or talkgroup until it ends, then resumes scanning. Priority channels or talkgroups are scanned more frequently, and their calls take precedence.

While the radio is scanning for activity, the animated  icon appears on the display.

When the radio stops on a channel or talkgroup where there is activity, the  icon flashes.

In a background or talkgroup scanning group, a scanning icon with a tick  indicates that the selected channel or talkgroup is a member of the scanning group.

There are four types of scanning:

- standard scanning (P25 conventional and analog channels)
- background scanning (P25 conventional and analog channels, and may include some voting groups)
- in-zone scanning (P25 conventional and analog channels, and P25 trunked talkgroups)
- talkgroup scanning (P25 trunked talkgroups, and may include some P25 conventional and analog channels)

For information about viewing and editing scanning group membership, see [Editing a Scanning Group on page 78](#).

8.2 Activating Standard Scanning

A standard scanning group scans conventional channels (P25 and analog) from across zones, and can also scan one or two voting groups. A standard scanning group appears and behaves on the radio like a separate channel, and all standard scanning groups are included in the channel list. Standard scanning is activated when a standard scanning group is selected.

8.2.1 Selecting a standard scanning group

1. Press **Menu** and select **Channels**.
2. Scroll to the required group and press **Select**.



Depending on how the radio is programmed, you may be able to press a function key or use the channel selector or Quick Access menu to select channels.

8.3 Activating Background Scanning

A background scanning group scans the group members, as well as the current channel selected on the radio. The group member channels can include conventional channels (P25 or analog) across zones, and can also include one or two voting groups.

Background scanning provides more flexibility than standard scanning, as you can select a current channel to operate on, while still monitoring permanent group members for activity.

8.3.1 Turning a background scanning on:

- Press **Menu** and select **Radio settings > Functions > Scanning**, or press the function key programmed for background scanning.

Background scanning remains on until you either press the function key again, or select a standard, in-zone or talkgroup scanning group.

8.3.2 Changing the background scanning group assigned to the function key

1. Press **Menu** and select **Radio settings > Functions > Set scan key**.
2. Scroll through the list of background scanning groups available and press **Select**. When you next turn on background scanning, this is the scanning group that is activated.

This is also available for talkgroup and In-zone scanning. See [Activating Talkgroup Scanning on the next page](#) and [Activating In-Zone Scanning on the next page](#).

8.4 Activating In-Zone Scanning

An in-zone scanning group scans the first 80 conventional channels (P25 or analog) or trunked talkgroups from the currently-selected zone. If zones are changed, the radio stops scanning the previous zone's channels and automatically starts scanning channels from the new zone.

In-zone scanning is useful when scanning conventional channels and trunked talkgroups from within the selected zone, and zones are used to separate different geographic regions or work roles. As you change to a new region or role, you can change to another zone and the radio will automatically start scanning channels or talkgroups in the new zone with no further action required.

8.4.1 Turning in-zone scanning on

- Press **Menu** and select **Radio settings > Functions > Scanning**, or press the function key programmed for in-zone scanning.



In-zone scanning remains on until you either press the function key again, or select a standard, background or talkgroup scanning group.

8.5 Activating Talkgroup Scanning

Talkgroup scanning monitors calls from multiple trunked talkgroups, and up to five additional conventional channels (P25 or analog), from across zones.



If a talkgroup scanning group contains P25 or analog conventional channels, scanning needs to exit trunked mode briefly to scan the conventional channels. This may result in delayed or even missed calls.

Talkgroup scanning is useful if you need to operate across multiple trunked talkgroups. When talkgroup scanning is activated, the currently-selected talkgroup or channel is temporarily included in the scanning group. If you change zones, the radio continues to monitor group members as well as the currently selected talkgroup or channel from the new zone.

8.5.1 Turning talkgroup scanning on

- Press **Menu** and select **Radio settings > Functions > Scanning**, or press the function key programmed for talkgroup scanning.



Talkgroup scanning remains on until you either press the function key again, or select a standard, background or in-zone scanning group.

8.6 Making a Call While Scanning

1. Press the PTT button to transmit.

The channel that is called depends on the way the radio has been programmed.

The possible options are:

- the radio calls a predetermined channel, e.g. the dispatcher
- the radio calls the channel where activity was last detected
- the radio calls the last free channel

2. When the called party responds, proceed with your conversation.

8.7 Suspending a Channel from a Scanning Group

If a group member is busy for a long time and you do not want to hear the conversation, use the function key programmed for nuisance delete to temporarily delete the group member. When the scanning group is next selected, or after the radio has been turned off and then on, the deleted member is again part of the scanning group.

8.7.1 Temporarily removing a captured group member from the scanning group

1. Press the function key programmed for nuisance delete.
2. If the channel is removed successfully, the message **Channel nuisance deleted** appears in the display.



The function key programmed to activate scanning may be programmed so that a short key press activates scanning and a long key press activates nuisance delete.

8.8 Editing a Scanning Group

8.8.1 Selecting a group to edit

1. Press **Menu** and select **Radio settings > Functions > Advanced > Edit groups**. The **Edit Groups** menu lists all scanning groups programmed for the radio.
2. Scroll to the group to be viewed or edited, press **Select**.
3. In the **Edit Group** menu, select from the following options:
 - **Group members**: shows the current members of a group, and may also show the designated transmit channel and priority channels.
 - **Add or Delete channel**: adds or deletes member channels of a group.
 - **Change tx**: changes the group's transmit channel.
 - **Change P1 or P2**: changes the group's first or second priority channel.



Depending on how the radio is programmed, you may be able to press a function key or use your Quick Access menu to select the Edit Groups menu.

8.8.2 Icons and meanings

Table 8.1 below features icons that may appear when viewing group membership details, adding or deleting channels from a group, or changing a group's transmit or priority channels.

Table 8.1 Icon Meanings

Icon	Meaning
T_X	This channel is used to transmit on when there has been no recent activity. You cannot delete this channel (it will not appear under Delete channel).
P_1	This channel is the group's first priority channel. You cannot delete this channel (it will not appear under Delete channel).
P_2	This channel is the group's second priority channel. Deleting this channel is configurable.
+	There is more than one instance of this channel in the group (the channel will be scanned more often). If this channel is deleted, the radio will attempt to delete all instances of the channel.

8.8.3 Viewing group membership

1. In the **Radio settings** menu, select **Edit groups** and select a scanning group. Press **Select**.
2. In the **Edit Group** menu, select **Group members** and press **Select**.
3. Scroll through the list of group members. The names of the group members may be shortened.

8.8.4 Adding a channel to a group

1. In the **Radio settings** menu, select **Edit groups** and select a scanning group. Press **Select**.
2. In the **Edit Group** menu, select **Add channel** and press **Select**. A list of channels that are not group members appears.
3. Select the channel to be added and press **OK**.

For all types of scanning except standard scanning, if the radio is programmed to use the scroll keys to scroll through a list of channels and also has a function key programmed to Nuisance Delete, you can **permanently** add or delete a channel to the active group by scrolling to the channel and pressing the **Nuisance Delete** function key.

8.8.5 Deleting a channel from a group

The priority 1 channel cannot be deleted using the Delete Channel menu.

1. In the **Radio settings** menu, select **Edit groups** and select a scanning group. Press **Select**.
2. In the **Edit Group** menu, select **Delete channel** and press **Select**. A list of group members that are able to be deleted appears.
3. Select the channel you want to delete and press **OK**.

For all types of scanning except standard scanning, if the radio is programmed to use the scroll keys to scroll through a list of channels and also has a function key programmed to Nuisance Delete, you can **permanently** add or delete a channel to the active group by scrolling to the channel and pressing the **Nuisance Delete** function key.

8.8.6 Changing a group's transmit channel



The group's transmit channel can only be changed if it has been pre-programmed.

1. In the **Radio settings** menu, select **Edit groups** and select a scanning group. Press **Select**.
2. In the **Edit Group** menu, select **Change tx** and press **Select**.

The current transmit channel is highlighted at the top of the list.

3. Select the new transmit channel and press **OK**.

The transmit channel remains changed even after the radio is turned off.

8.8.7 Changing a group's first or second priority channel

1. In the **Radio settings** menu, select **Edit groups** and select a scanning group. Press **Select**.
2. In the **Edit Group** menu, select **Change P1** or **Change P2** and press **Select**.

The current priority channels are highlighted at the top of the list.

3. Select the new priority 1 or priority 2 channel and press **OK**.

9 Location Services

This section explains how to use the location services that may be available on the radio.



This feature is controlled by a SFE and may not be available with the radio by default.

9.1 About Location Information

The radio can display location information such as latitude and longitude, true course, speed, and coordinated universal time. The radio can also display universal transverse mercator (UTM) information such as the UTM zone, and northing and easting coordinates.

The radio can also be set up to send and log location information.

9.2 About Location Statuses

On the **Own location** screen, the following location status information appears on the display:

- **Trk/tracking:** the receiver is displaying up-to-date satellite information.
- **stored:** the receiver is having trouble connecting to satellites and the radio is displaying stored information that may not be current.
- **no cnx:** the radio has lost serial communications with the GNSS receiver.

The information displayed can be sent to other radios on the network by pressing the **Share** selection key.

9.3 Viewing Location Information

The radio can be programmed to show various displays. Initially, location reporting is set to all zeros until the first satellite fix. Latitude and longitude formats depend on the configuration. In certain situations, the radio may automatically exit the location display.

Location information is displayed if it is available and configured to be visible. The images below show some of the available options.

1. Press **Menu** and select **Location Svs > Own location**.
2. Use the scroll keys to scroll through the **Own location** displays.




Figure 9.1 Latitude and longitude in degrees, minutes and decimal seconds




Figure 9.2 The radio's current course and speed




Figure 9.3 UTC: Coordinated Universal Time, 24-hour clock

3. Press **Exit** to exit the location display.

10 Loneworker Monitoring

Loneworker monitoring is a safety feature for people who work alone. Loneworker monitoring can be programmed to be on or off at all times, or you can switch it on and off using a programmed function key or the menu.

A loneworker alarm is activated if, for a set period of time, the radio is tilted beyond a certain angle (man down), remains stationary, or shows no user activity.

The radio may be programmed to respond to a combination of these events.

When the predetermined time has expired, an audible warning is given and you will have a predetermined time to respond to the warning.

If you are unable to respond, the radio either enters emergency mode or (in digital mode) sends a status update to a predetermined person or talkgroup.

10.1 Activating Loneworker Monitoring

1. Press **Menu** and select **Radio Settings > Extra features > Loneworker**.
2. In the **Loneworker** menu, select **On**.

A vertical scroll bar on the right-hand side of the display indicates the remaining activity timeout. To reset the count-down bar, press any key.




Figure 10.1 Radio display when loneworker is activated

10.2 Responding to a Loneworker Alarm

When the radio beeps, you need to respond to confirm your safety. The message **Loneworker awaiting** and a horizontal scroll bar appear, showing the remaining time until an emergency action is triggered (see [Figure 10.2 below](#)).



Figure 10.2 Loneworker awaiting message

There are ways to respond to the Loneworker awaiting message:

- press any key
- move the radio
- if using the man down feature, restore the radio to an upright position

If no action is taken, the radio will activate emergency mode or send a status update in digital mode.

11 Encryption

This section describes how to use encryption to make your communications completely private.



This feature is controlled by a SFE and may not be available with the radio by default.

11.1 About Encryption



The encryption feature is available for digital networks only.

To ensure private communication among the other radio users in your system, your radio may be able to encrypt outgoing calls using a confidential encryption key. The receiving radio must have the same encryption key installed to hear the encrypted call.


11.1.1 About the proper key detect feature

Encryption does not need to be enabled for the radio to unmute.

The radio may be programmed with 'proper key detect'. This means that you can only hear an encrypted call if the key used to encrypt the incoming call matches the key used to encrypt your outgoing calls on that channel.

For example, you are encrypting your outgoing calls using encryption **key 7**. Although **key 1** and **key 2** are also stored in the radio, the radio has been programmed to unmute only the incoming calls encrypted using **key 7**.

11.2 Encrypting Calls

Encryption can be turned on and off. While encryption is on, outgoing calls are encrypted on networks programmed for encryption, and the encryption icon  remains in the display.

This setting only affects outgoing calls. Incoming calls will still be decoded by the radio as long as the key required to decode the call is stored in the radio.

11.2.1 Turning encryption on or off

Using the main menu

1. Press **Menu** and select **Security > Encryption**.
2. Scroll to **On** (or **Off**) and press **Select**.

The message **Encryption activated** (or **deactivated**) appears in the display.




Depending on how the radio is programmed, you can press a function key to turn encryption on and off.


Using the 3-way selector

- Turn encryption on by rotating the 3-way selector to either position A or B. The message **Encryption activated** briefly appears in the display.
- Turn encryption off by rotating the 3-way selector to position C. The message **Encryption deactivated** briefly appears in the display.

11.3 Making an Encrypted Call

1. Select the desired network to operate on or channel or group.
2. Check that encryption is on (encryption key  is showing in the display).
3. Press and hold the PTT button to transmit.

The name of the encryption key that the radio is using for the transmission may briefly appear in the display.

Call details appear on the display, the LED glows red, and  appears on the display.

11.4 Receiving an Encrypted Call

When receiving an encrypted call, the radio unmutes and clear speech can be heard, so long as the key required to decode the call is stored in the radio.

The name of the encryption key used to encrypt the incoming call may briefly appear in the display, below the name of the caller.

If the key required to decode the call is not stored in the radio, then the radio remains muted.

The radio may also remain muted if the currently selected channel has 'proper key detect' programmed.

11.5 Changing the Radio's Encryption Key

The **Change All** menu can be used to change the encryption key that encrypts outgoing calls. The **Preset Keys** menu can then be used to change the encryption keys back to the default encryption key for each channel.

Once the encryption key is changed, the encryption keys used to encrypt calls on other channels will also be updated.

11.5.1 Changing the transmit encryption key

1. Press **Menu** and select **Security > Change all**.
2. Scroll to the required key and press **Select**. The message **Global key selected** briefly appears in the display.

11.5.2 Changing the transmit encryption key back to the default setting

1. Press **Menu** and select **Security > Preset keys**. The message **Select preset keys?** appears in the display.
2. Press **OK** and the message **Preset keys selected** briefly appears in the display.

11.5.3 Changing the encryption keyset

Take the following steps to change the encryption data associated with the encryption keys loaded in the radio:

1. Select **Menu > Security > Security > Change keyset**.
2. Scroll to **01** or **02** and press **Select**. The message **Keyset selected** briefly appears in the display.

11.6 Removing Encryption Keys from the Radio

You can delete encryption keys from your radio.



Caution When emergency mode is activated, or when the radio is immobilized ('inhibited'), encryption keys may be automatically deleted from the radio.

If the encryption keys are deleted, the message **Key fail** appears and a warning tone will periodically sound. The message **Cannot transmit** will be displayed if you try to transmit.

11.6.1 Deleting an encryption key

1. Press **Menu** and select **Security > Advanced > Zeroize key**.
2. Scroll to the desired key and press **Select**. The message **Single key zeroized** briefly appears in the display.

11.6.2 Deleting all encryption keys

1. Press **Menu** and select **Security > Advanced > Zeroize all**. The message **Zeroize all keys?** appears in the display.
2. Press **OK** and the message **All keys zeroized** briefly appears in the display.

11.7 Updating Encryption Keys Over-The-Air

Encryption keys can be updated using over-the-air-rekeying (OTAR).



This feature is controlled by a software license (SFE) and may not be available with the radio by default.

This feature is only available for digital channels.

1. press **Menu** and select **Security > OTAR > Rekey request**.

The message **Rekey request ack** appears in the display. If there is no response to the rekey request, the message **Rekey request timeout** appears.

12 Customizing Radio Settings



These features are common to radios operating in either trunked or conventional mode.

12.1 Extending Battery Life on Shift

The radio's power consumption can be reduced (thereby extending the life of the battery during a shift) in the following ways:

- transmit at low power (if the radio is not already configured to do this)
- ensure that backlighting automatically turns off when no radio activity is detected (see [Turning on Backlighting on page 93](#))

12.1.1 Turning low power transmit on or off

If the radio is being used in conditions where signal strength is high, the battery's shift life can be extended by transmitting at low power.

When low power transmit is turned on, **L** or **L** with a signal icon appears in the display and calls are made at low power rather than at the programmed power setting.

Using the main menu

1. Press **Menu** and select **Radio settings > Functions > Low power tx**.
2. Scroll to **On** (or **Off**) and press **Select**.

The current setting is highlighted.

The message **Low power tx activated** (or **deactivated**) appears on the display.

Using a function key

1. Press the function key programmed for low-power transmit to transmit at low power on your current channel and any channels subsequently used.



The message **Low power tx activated** appears briefly, and the low-power transmit icon **L** or **L** with a signal icon appears on the display.

When the radio is not transmitting, the letter 'L' is displayed. When the radio is transmitting, a single arrow appears beside the 'L'.

2. Press the low-power transmit function key again to turn low-power transmit off, and the message **Low power tx deactivated** appears on the display.

12.2 Changing the Color Mode

The display colors can be changed to suit the environment. For example, Red/Black is suited for night display while Color - Dark is ideal for bright environments. The default setting is Color - Light.

12.2.1 Changing the color mode:

1. Press **Menu** and select **Radio settings > Display settings > Color mode**.
2. Scroll to the desired mode and press **Select**.

Table 12.1 below features the available color modes.

Table 12.1 Color modes

Mode	Description
Color - Dark	Dark background, light text
Color - Light	Default setting. Light background, dark text. Best suited for day time display
Black/White	White background, black text
White/Black	Black background, white text
Red/Black	Black background, red text. Best suited for night display

12.3 Changing the Volume of all Audible Indicators


You can set the volume of all the audible indicators to either high or low. Audible tones include incoming call tones, warning tones and confirmation tones.

12.3.1 Changing the volume of the radio's audible tones



Depending on how the radio is programmed, you are able to press a function key to change the level of indicators.

1. Press **Menu** and select **Radio settings > Alert settings > Indicator level**.




2. Scroll to **High** (or **Low**) and press **Select**.

12.4 Changing the Volume of Keypress Tones

Whenever you press the radio keys, the keypress tones make an audible indication as to whether or not your action is allowed. A short, medium-pitched beep indicates that an action is allowed. A long, low-pitched beep indicates that the action is not allowed.

12.4.1 Changing the volume of the radio's keypress tones

1. Press **Menu** and select **Radio settings > Alert settings > Keypress tones**.



2. Scroll to either **Off**, **Low** or **High** and press **Select**.




Depending on how the radio is programmed, you may be able to press a function key to toggle keypress tones on and off, and to change between high and low volume.

12.5 Changing to Quiet Operation

When quiet operation is on, keypress tones and confirmation tones are turned off. Incoming call tones, signaling tones and warning tones all remain audible.

12.5.1 Turning quiet operation on or off

1. Press **Menu** and select **Radio settings > Alert settings > Quiet operation**.



2. Scroll to **On** (or **Off**) and press **Select**.




Depending on how the radio is programmed, you may be able to press a function key to toggle quiet operation on and off.

12.6 Changing to Silent Operation


When silent operation is on, all the radio's audible tones are turned off, and only channel traffic can be heard.

12.6.1 Turning silent operation on or off

1. Press **Menu** and select **Radio settings > Alert settings > Silent operation**.



2. In the **Silent operation** menu, scroll to either **On** or **Off** and press **Select**.

While silent operation is on, the  icon appears in the display.




Depending on how the radio is programmed, you may be able to press a function key to toggle silent operation on and off.

12.7 Turning on Backlighting

If configured, whenever a key is pressed or a call is received, the keypad and display will light up automatically. Backlighting only remains on for a few seconds, unless there is further radio activity. When backlighting is turned on, it remains on until the setting is changed to **Off**, regardless of radio activity.

12.7.1 Turning backlighting on or off

1. Press **Menu** and select **Radio settings > Display settings > Backlighting**.



2. Scroll to either **On** or **Off** and press **Select**.



Depending on how the radio is programmed, you may be able to press a function key to toggle backlighting on and off, or between 'with activity' and 'on'.

12.7.2 Turning backlighting on momentarily

You may be able to use a programmed function key to turn backlighting on momentarily, as long as backlighting has been configured to 'with activity'.

- Press the assigned function key to turn backlighting on. Backlighting remains on for a few seconds, and then turns off.

Alternatively, the function key may be programmed so that:

- a short key press turns backlighting on momentarily, and
- a long key press turns backlighting on, and it remains on until there is a further long key press.

12.8 Adjusting the Display Orientation

12.8.1 Rotating the display

1. Press **Menu** and select **Radio settings > Display settings > Rotate display**.
2. Scroll to **On** (or **Off**) and press **Select**.



Caution When the display is rotated, everything appears upside down.



Depending on how the radio is programmed, you may be able to press a function key to toggle rotate display on and off.

13 Failsoft Mode Operation

If the radio is programmed to enter failsoft mode, it does not have access to the trunking system. Failsoft mode operates in two ways:

- 'radio-based' failsoft
- 'infrastructure' failsoft

13.1 Radio-based Failsoft

When access to the trunking system is lost,  no longer appears, the bars in the RSSI icon  disappear and the display shows **No service**.

After a short time, the radio switches to a programmed conventional communications channel.

The radio remains on that channel until you select a trunked talkgroup with access to the trunking system.

13.2 Infrastructure Failsoft

The radio receives a message from the trunking infrastructure to say that the trunking system is now operating in failsoft mode.

While in failsoft mode, the display shows **Failsoft**, and the radio sounds a repeating double beep. The double beep continues until normal service is restored.

You may still be able to communicate with your dispatcher and other talkgroup members, depending on the type of system failure that has occurred, and how the radio is programmed.

When the trunking system returns to normal operation, the radio is notified, and will attempt to register on the control channel it was previously using.

14 Troubleshooting




This section describes troubleshooting procedures and basic maintenance.




If you are experiencing difficulty operating the radio, you may find the following sections helpful. Consult the radio provider for assistance, if necessary.

14.1 Unconnected Calls

[Table 14.1 below](#) explains the way a radio behaves if a call is not connected.

Table 14.1 Radio behavior of unconnected calls

Radio behavior	Explanation
	The system is too busy to process your talkgroup or individual call.
 The radio sounds three short beeps	The system is now available to process your talkgroup or individual call.
 The radio sounds five beeps, followed by a repeating double beep	You have selected a talkgroup that does not currently exist on the system. The display shows that service is lost, and TY no longer appears. See Service is lost on page 61

Radio behavior	Explanation
 <p>The radio sounds two short beeps</p>	<p>You have attempted to make an individual call to a radio that does not currently exist on the system.</p>
 <p>The radio sounds two short beeps</p>	<p>You have attempted to make an individual call to a radio that has never existed on the system.</p>
 <p>The radio sounds two short beeps</p>	<p>You have attempted to make an individual or phone call, but you are not authorized to do this.</p> <p>Your individual or phone call has been rejected or is unanswered.</p>

14.2 The Radio won't Turn On

If the radio LED doesn't light up red briefly when the radio is turned on, power is likely not reaching the radio. Check one or more of the following:

- Is the battery firmly attached to the radio?
- Is the battery sufficiently charged?
- Is the battery charger working properly?

If all appears to be in order, but the radio still fails to operate properly, contact the radio provider for further assistance.

14.3 Identifying the Radio's Audible Tones

The radio's audible tones can help you identify a potential problem. See [Understanding the Radio Indicators on page 34](#).

14.4 Viewing Radio Information

Use the **Radio info** menu to view information such as the hardware and firmware version of the radio, function key settings, the radio serial number, and various radio identities.

1. Press **Menu** and select **Radio settings > Radio info**.
2. Scroll to the radio information you want to view and press **Select**.

14.4.1 Checking the version of the radio using the PTT button

1. Turn off the radio.
2. Hold down the PTT button and turn on the radio.

The firmware and hardware versions and the radio's frequency band is briefly displayed.

14.5 General Care

The only radio maintenance required is ensuring the battery has sufficient charge and that the antenna and battery are not damaged or dirty.

To prevent permanent damage to the radio case, do not allow the radio to come into contact with detergents, alcohol, aerosol sprays, or petroleum-based products.

14.5.1 Cleaning the radio



Caution - Risk of permanent damage to the radio housing! Do not clean the radio with solvents or alcohol based products. This includes (but is not limited to) ethylene glycol (antifreeze), propanone (acetone), ethanol (methylated spirits), isopropyl alcohol, and pool chlorine (calcium hypochlorite).

1. Use a lint-free, dry cloth to remove surface dirt, oil, or grease.
2. Use an alcohol-free, antibacterial wipe to disinfect the radio.
3. Use a water-dampened, lint-free, microfibre cloth to remove any remaining dirt.
4. If the damp cloth is ineffective, dilute a (5 to 10%) solution of alcohol-free dishwashing liquid in clean water, on a cloth, to remove remaining dirt.
5. If the dish-washing liquid solution is ineffective, use a solution of one part household bleach to two parts clean water, on a cloth, to wipe away remaining dirt.



Caution Always use protective equipment (gloves, face mask) when handling bleach.



Caution Risk of internal damage! To avoid damaging the inside of the radio, do not allow excess liquid to enter the radio body (speaker grille, keypad, buttons, and connectors).

14.5.2 Cleaning the contacts of the battery

Do not scratch or scrape the contacts of the battery. If necessary, wipe the contacts of the battery with a dry, lint-free cloth to remove any dirt, oil or grease.

14.6 Running Diagnostic Tests

Diagnostics tests are available via the main menu.



This feature is controlled by a SFE and may not be available with the radio by default.

1. Press **Menu** and select **Diagnostics**.
2. Scroll to the name of the required test and press **Select**.



The radio may transmit when you select some tests. Make sure you have a suitable load or antenna connected before running diagnostics tests.

Table 14.2 Diagnostic tests

Test	Description
Audio loopback test	<p>Routes audio from an external accessory microphone to the radio's internal speaker.</p> <p>Before running this test, turn the volume down to limit interference and reduce the impact of audio artifacts.</p>
Display freq	Displays the transmit and receive frequencies of the current channel. Also displays the channel status (CNV, TCH, CCH) and the mode (ANA, PH1 or PH2). If the radio is scanning, this information may not be available.
Display test	Displays a test screen of all colors that appear on the screen. Useful for identifying dead pixels.
Keypad test	Sounds an audible tone when a key is pressed or released on the radio, or the 16-way and 3-way selectors are moved. The radio also displays the key or selector name along with "pressed" or "released" or the new selector position.
QoS	Displays information about the quality of service (received signal strength (RSSI) with an indication of digital voice quality). Also displays the channel status (CNV, TCH, CCH) and the mode (PH1 or PH2).
RSSI	Displays the received signal strength (RSSI) of the current channel.
Rx tone	Receives a 1011Hz or 1031Hz tone and displays the received signal strength (RSSI) and the bit error rate (BER) of the received signal. Also displays the channel status (CNV, TCH, CCH) and the mode (PH1 or PH2). On a P25 conventional channel, you can select whether to receive a 1011Hz (Phase 1) or 1031Hz (Phase 2) tone. On a P25 trunked channel, the network selects whether 1011Hz or 1031Hz is used.
Site display	Shows the channel number, signal strength and system-identity code (SYSCODE) for the currently registered trunked site.
Site measure	Lists the current trunked site (indicated with an asterisk) and up to six detected adjacent sites, with received signal strength (RSSI) information.
Tone test	Generates an audible tone for the duration of the test.
Tx Tone	Transmits a tone of 1011Hz or 1031Hz on the current P25 channel.
Tx Tone Cal	Transmits a 1011Hz or 1031Hz tone on the current channel with a bit error rate (BER) of 5%.
Tx power test	Displays hardware-related information while the radio is transmitting. Information includes the final PA current (in mA).

<https://www.taitcommunications.com/our-resources/compliance/declarations-of-conformity>

LT Aš, Tait International Limited, patvirtinu, kad radijo įrenginių tipas TPAB1A, TPAH5A, TPAH6A, TPCB1A, TPCC0A, TPCH5A, TPCH6A, TPDB1A, TPDB1B, TPDB1C, TPDB1D, TPDC0A, TPDC0D, TPDH5A, TPDH5D, TPDH7A, TPDH7D, TPDHBB, TPDHKB, TPDH7C, TUFM2D, TUFM3A, TPGb1A, TPGHKA, TPGH7A & TPN0A atitinka Direktyvą 2014/53/ES. Visas ES atitikties deklaracijos tekstas prieinamas šiuo interneto adresu: <https://www.taitcommunications.com/our-resources/compliance/declarations-of-conformity>

HU Tait International Limited igazolja, hogy a TPAB1A, TPAH5A, TPAH6A, TPCB1A, TPCC0A, TPCH5A, TPCH6A, TPDB1A, TPDB1B, TPDB1C, TPDB1D, TPDC0A, TPDC0D, TPDH5A, TPDH5D, TPDH7A, TPDH7D, TPDHBB, TPDHKB, TPDH7C, TUFM2D, TUFM3A, TPGb1A, TPGHKA, TPGH7A & TPN0A típusú rádióberendezés megfelel a 2014/53/EU irányelvnek. Az EU-megfelelőségi nyilatkozat teljes szövege elérhető a következő internetes címen: <https://www.taitcommunications.com/our-resources/compliance/declarations-of-conformity>

MT B'dan, Tait International Limited, niddikjara li dan it-tip ta' tagħmir tar-radju TPAB1A, TPAH5A, TPAH6A, TPCB1A, TPCC0A, TPCH5A, TPCH6A, TPDB1A, TPDB1B, TPDB1C, TPDB1D, TPDC0A, TPDC0D, TPDH5A, TPDH5D, TPDH7A, TPDH7D, TPDHBB, TPDHKB, TPDH7C, TUFM2D, TUFM3A, TPGb1A, TPGHKA, TPGH7A & TPN0A huwa konformi mad-Direttiva 2014/53/UE. It-test kollu tad-dikjarazzjoni ta' konformità tal-UE huwa disponibbli f'dan l-indirizz tal-Internet li ġej: <https://www.taitcommunications.com/our-resources/compliance/declarations-of-conformity>

NL Hierbij verklaar ik, Tait International Limited, dat het type radioapparaat TPAB1A, TPAH5A, TPAH6A, TPCB1A, TPCC0A, TPCH5A, TPCH6A, TPDB1A, TPDB1B, TPDB1C, TPDB1D, TPDC0A, TPDC0D, TPDH5A, TPDH5D, TPDH7A, TPDH7D, TPDHBB, TPDHKB, TPDH7C, TUFM2D, TUFM3A, TPGb1A, TPGHKA, TPGH7A & TPN0A conform is met Richtlijn 2014/53/EU. De volledige tekst van de EU-conformiteitsverklaring kan worden geraadpleegd op het volgende internetadres: <https://www.taitcommunications.com/our-resources/compliance/declarations-of-conformity>

PL Tait International Limited niniejszym oświadczam, że typ urządzenia radiowego TPAB1A, TPAH5A, TPAH6A, TPCB1A, TPCC0A, TPCH5A, TPCH6A, TPDB1A, TPDB1B, TPDB1C, TPDB1D, TPDC0A, TPDC0D, TPDH5A, TPDH5D, TPDH7A, TPDH7D, TPDHBB, TPDHKB, TPDH7C, TUFM2D, TUFM3A, TPGb1A, TPGHKA, TPGH7A & TPN0A jest zgodny z dyrektywą 2014/53/UE. Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: <https://www.taitcommunications.com/our-resources/compliance/declarations-of-conformity>

PT O(a) abaixo assinado(a) Tait International Limited declara que o presente tipo de equipamento de rádio TPAB1A, TPAH5A, TPAH6A, TPCB1A, TPCC0A, TPCH5A, TPCH6A, TPDB1A, TPDB1B, TPDB1C, TPDB1D, TPDC0A, TPDC0D, TPDH5A, TPDH5D, TPDH7A, TPDH7D, TPDHBB, TPDHKB, TPDH7C, TUFM2D, TUFM3A, TPGb1A, TPGHKA, TPGH7A & TPN0A está em conformidade com a Diretiva 2014/53/UE. O texto integral da declaração de conformidade está disponível no seguinte endereço de Internet: <https://www.taitcommunications.com/our-resources/compliance/declarations-of-conformity>

RO Prin prezenta, Tait International Limited declară că tipul de echipamente radio TPAB1A, TPAH5A, TPAH6A, TPCB1A, TPCC0A, TPCH5A, TPCH6A, TPDB1A, TPDB1B, TPDB1C, TPDB1D, TPDC0A, TPDC0D, TPDH5A, TPDH5D, TPDH7A, TPDH7D, TPDHBB, TPDHKB, TPDH7C, TUFM2D, TUFM3A, TPGb1A, TPGHKA, TPGH7A & TPN0A este în conformitate cu Directiva 2014/53/UE. Textul integral al declarației UE de conformitate este disponibil la următoarea adresă internet: <https://www.taitcommunications.com/our-resources/compliance/declarations-of-conformity>

SK Tait International Limited týmto vyhlasuje, že rádiové zariadenie typu TPAB1A, TPAH5A, TPAH6A, TPCB1A, TPCC0A, TPCH5A, TPCH6A, TPDB1A, TPDB1B, TPDB1C, TPDB1D, TPDC0A, TPDC0D, TPDH5A, TPDH5D, TPDH7A, TPDH7D, TPDHBB, TPDHKB, TPDH7C, TUFM2D, TUFM3A, TPGb1A, TPGHKA, TPGH7A & TPN0A je v súlade so smernicou 2014/53/EÚ. Úplné EÚ vyhlásenie o zhode je k dispozícii na tejto internetovej adrese: <https://www.taitcommunications.com/our-resources/compliance/declarations-of-conformity>

SL Tait International Limited potrjuje, da je tip radijske opreme TPAB1A, TPAH5A, TPAH6A, TPCB1A, TPCC0A, TPCH5A, TPCH6A, TPDB1A, TPDB1B, TPDB1C, TPDB1D, TPDC0A, TPDC0D, TPDH5A, TPDH5D, TPDH7A, TPDH7D, TPDHBB, TPDHKB, TPDH7C, TUFM2D, TUFM3A, TPGb1A, TPGHKA, TPGH7A & TPN0A skladen z Direktivo 2014/53/EU. Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: <https://www.taitcommunications.com/our-resources/compliance/declarations-of-conformity>

FI Tait International Limited vakuuttaa, että radiolaitetyyppi TPAB1A, TPAH5A, TPAH6A, TPCB1A, TPCC0A, TPCH5A, TPCH6A, TPDB1A, TPDB1B, TPDB1C, TPDB1D, TPDC0A, TPDC0D, TPDH5A, TPDH5D, TPDH7A, TPDH7D, TPDHBB, TPDHKB, TPDH7C, TUFM2D, TUFM3A, TPGb1A, TPGHKA, TPGH7A & TPN0A on direktiivin 2014/53/EU mukainen. EU-vaatimusten mukaisuus-vakuutuksen täysimittainen teksti on saatavilla seuraavassa internetosoitteessa: <https://www.taitcommunications.com/our-resources/compliance/declarations-of-conformity>

SV Härmed försäkrar Tait International Limited att denna typ av radioutrustning TPAB1A, TPAH5A, TPAH6A, TPCB1A, TPCC0A, TPCH5A, TPCH6A, TPDB1A, TPDB1B, TPDB1C, TPDB1D, TPDC0A, TPDC0D, TPDH5A, TPDH5D, TPDH7A, TPDH7D, TPDHBB, TPDHKB, TPDH7C, TUFM2D, TUFM3A, TPGb1A, TPGHKA, TPGH7A & TPN0A överensstämmer med direktiv 2014/53/EU. Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande webbadress: <https://www.taitcommunications.com/our-resources/compliance/declarations-of-conformity>